


Plastic Safety Handles (PAIR) (07-0005)

1. Place Plastic Safety Handle upon a flat surface such as a 4 x 4 or 2 x 4 vertical wood component. The wood may be slightly inclined forward from vertical.

!WARNING! PLASTIC SAFETY HANDLES ARE NOT FOR OVERHEAD USE AND ARE NOT TO SUPPORT THE FULL OR PARTIAL HANGING WEIGHT OF A PERSON OR OBJECT. DO NOT ATTACH CHAINS, PET LEASHES, ROPES OR ANY OTHER OBJECTS TO THE PLASTIC SAFETY HANDLES.

2. Fasten the Plastic Safety Handle to the wood component with the 1-1/4" pan head screws and washers provided.



FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11