

# Abby's Palace

ASSEMBLY MANUAL

Copyright © 2011 PlayNation Play Systems, Inc.

All Rights Reserved

www.PlayNation.com • 190 Etowah Industrial Court • Canton, GA 30114 • (800) 661-7295

Latest Revision: December 20, 2011

# TABLE OF CONTENTS

Warranty and Safety Guidelines.....	Pages 3-12
Leveling Play Set, General Information and Definitions.....	Pages 12-14
Site Plan, Kit Contents and Tool List.....	Pages 15-16
<b>UNIT A</b> (Left side as you face the front of the playset.).....	Pages 17-91
Hardware, Lumber and Accessory Checklist.....	Pages 18-28
Framing Lower Level.....	Steps 1-7
Lower Level Deck Panels and Deck Spacers.....	Steps 8-9
Side Panels and Safety Boards.....	Steps 10-12
Climbing Ramp Assembly and Installation.....	Steps 13-17
Framing Upper Level.....	Steps 19-26
Upper Level Deck Panel and Deck Spacers.....	Steps 27-28
CL Steps and Post Panel.....	Steps 29-30
Picnic Table Assembly.....	Steps 31-33
Lower Level Roof, Sunburst and Dormer Installation.....	Steps 34-46
Top Panel Boards.....	Step 47
Upper Level Roof Installation.....	Step 48-50
Trapeze Arm Assembly and Installation.....	Steps 51-52
Telescope, Flags, Super Tube Slide, Metal/Plastic Safety Handles, Scoop Slide, Tire-Swing, Trapeze Installation.....	Steps 53-60
Logo Plate Installation.....	Step 61

**PLEASE READ OWNER'S MANUAL CAREFULLY  
BEFORE STARTING ASSEMBLY!**



# TABLE OF CONTENTS

<b>UNIT C</b> (Right side as you face the front of the playset).....	Page 93-155
Hardware, Lumber and Accessory Checklist.....	Pages 94-104
Framing Lower Level.....	Steps 1-7
Lower Level Deck Panels and Deck Spacers.....	Steps 8-9
Ladder and Metal Safety Handles.....	Step 10
Side Wall Panels.....	Step 11
Lower Level Roof and Sunburst Installation.....	Steps 12-15
Door Wall Panel, Filler Board and Door Installation.....	Steps 16-17
Dormer and Porch Roof Panel Installation.....	Steps 18-19
Front Porch Panels and Top Panel Board.....	Steps 20-21
Upper Level Framing and CL-Steps.....	Steps 22-31
Upper Level Deck Panel and Deck Spacers.....	Steps 32-33
Post Panel.....	Step 34
Picnic Table Assembly.....	Steps 35-36
Upper Level Roof Installation.....	Steps 37-38
Rope Ladder Support, Rope Ladder Runner and Rope Ladder Assembly.....	Step 39
Flower Box, Super Scoop Slide, Dinner Bell, Telescope, Flags, Steering Wheel, Plastic Safety Handles and Super Wave Scoop Slide Installation.....	Steps 40-46

**PLEASE READ OWNER'S MANUAL CAREFULLY  
BEFORE STARTING ASSEMBLY!**

# TABLE OF CONTENTS

<b>UNIT B</b> (Bridge centered between <b>UNIT A</b> and <b>UNIT C</b> playsets.).....	Pages 156-176
Hardware, Lumber and Accessory Checklist.....	Pages 157-160
Attaching Iron Ductile Swing Hangers.....	Step 1
Attaching 4 x 6 x 103” Beams to Playsets.....	Step 2
Attaching End Caps onto ends of 103” Beams.....	Step 3
Bridge Deck Installation.....	Step 4
Drill Corner Post Holes.....	Step 5
Install Corner Posts.....	Step 6
Install Bridge Railings.....	Step 7
Bridge Roof Sections and Roof Peak Installation.....	Steps 8-9
Chimney Installation.....	Step 10
Sunburst Installation.....	Steps 11-13
Attach Panel Slats.....	Step 14
Periscope.....	Step 15
Hang Swing Belts.....	Step 16
Customer Registration Card.....	Last Page

**PLEASE READ OWNER’S MANUAL CAREFULLY  
BEFORE STARTING ASSEMBLY!**



## IMPORTANT – PLEASE READ

As fresh lumber acclimates to its new environment, the natural tendencies of the tree can show itself in the form of checks, or “cracks” in the lumber. In almost all cases this is normal and it will not affect the structural integrity of your play set.

Cosmetic defects that do not affect the structural integrity of the product, or natural defects of wood such as warping, checking or any other physical properties of wood that do not present a safety hazard, are not covered by this warranty. Defects that develop because the product is exposed to extreme climate conditions are not covered by this warranty. Defects that develop as a result of faulty or improper installation of the product are also not covered by this warranty.

**Most cracks are not warrantable**, however if you believe that the integrity of your play set is compromised by this natural occurrence, please follow the warranty claim procedure found at [www.playnation.com](http://www.playnation.com). Click on the “Customer Care” tab on the left hand side of the page, then click on “Warranty Claim” and follow the instructions.

We appreciate your purchase and know that you will enjoy your play system for many years to come.

IF YOU HAVE MISSING OR DAMAGED PARTS OR NEED ASSISTANCE ASSEMBLING, PLEASE CALL PlayNation Play Systems, Inc. MANUFACTURING DIRECT.(800) 445-7529 FACTORY HOURS – MON.–FRI., 8AM-5PM EST DO NOT RETURN THIS PRODUCT TO THE RETAILER OR CONTACT THE RETAILER DIRECT. THE RETAILER DOES NOT STOCK COMPONENTS. PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. KEEP THEM IN A SAFE PLACE WHERE YOU CAN REFER TO THEM AS NEEDED.

### **CONTACT INFO:**

PlayNation Play Systems, Inc.  
190 Etowah Industrial Court  
Canton, GA 30114  
Tel. (770) 704-9300  
Fax. (678) 880-3300  
[custsrv@playnation.com](mailto:custsrv@playnation.com)

Check for revised instructions at [www.playnation.com/instructions.html](http://www.playnation.com/instructions.html)

## **Thank you for choosing PlayNation Play Systems, Inc.**

We've included everything you need, except tools, to build your very own professional looking play set. When complete, your new play set should far exceed the quality of play set kits from other build-your-own companies. Our engineers and design team have over 30 years of playground experience. What we've developed is a play set that doesn't compromise quality for simplicity. Yet you'll appreciate how quick and easy construction really is! Our play set kits are designed for children ages 3 to 11. PlayNation Play Systems, Inc. believes every child should have a play set and with our kits they can! You can rest assured your new play set is safe, durable and designed to hold up to the elements. As parents ourselves, we know how important the security and well-being of our children is, and this shows in all of our products.

Each play set features our step-by-step 3D illustrated manual, patented powder coated swing beam bracket, heavy-duty swing belts with chains, slide(s), accessories, plus all the required hardware and pre-milled lumber.

# Limited Manufacturers Warranty

PlayNation Play Systems, Inc. (“PlayNation”) warrants its Enchanted™, Dreamer™, and Majestic™ series of swing sets to be free from defects in workmanship and materials, under normal use and conditions, for the lifetime of the product for structural wood components and for two years for all other components (e.g., hardware, plastics, tarps, rope ladder, etc.) except PlayNation’s Super Scoop Slides™ and Super Tube Spiral Slides™.

PlayNation warrants its Super Scoop Slides™ and Super Tube Spiral Slides™ to be free from defects in workmanship and materials, under normal use and conditions, for the lifetime of the product.

Cosmetic defects or natural defects of wood (e.g., warping, seasonal checking or cracking, knots, or knot holes, etc.) that do not affect the structural integrity of the product are not covered by this warranty. Defects that develop because the product is exposed to extreme climate conditions, excessive water exposure, lumber that has been damaged by wood boring bees, or defects that develop as a result of faulty or improper installation of the product, are not covered by this warranty. Fading, discoloration or molding of any wood part or accessory, cracks in plastic components, surface rust on hardware, and chips on powder coated materials are not considered defects in material as long as they do not affect the functionality or structural integrity of the part or component.

It is the owner’s responsibility to properly maintain the play set. Instructions for proper maintenance can be found on PlayNation’s website. Imperfections or defects that develop because of a failure to properly maintain the play set are not covered by this warranty.

PlayNation will repair or, at its discretion, replace any part within the stated warranty period that is defective in workmanship or materials. This decision is subject to verification of the defect, which, at PlayNation’s discretion, may be accomplished by submitting photographs or by delivery of the defective part to PlayNation. Any warranty claim must include proof of purchase, including the date of purchase.

This warranty is valid only if the product is used for the purpose for which it was designed and installed at a residential, single-family dwelling. This warranty is void if the product is used for commercial, institutional or multi-family dwelling use. This warranty does not cover (a) products that have been damaged by acts of God, negligence, misuse, or accident, or that have been modified or repaired by unauthorized persons; (b) the cost of labor; or (c) the cost of shipping the product, any part, or any replacement product or part.

PLAYNATION DISCLAIMS ALL OTHER REPRESENTATIONS AND WARRANTIES OF ANY KIND, EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. PLAYNATION WILL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. This warranty is valid only in the United States of America, is nontransferable and does not extend to the owners of the product subsequent to the original purchaser. Some states do not allow limitations on implied warranties or exclusion of incidental or consequential damages, so these restrictions may not be applicable to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

# Important Safety Guidelines

This product is intended for residential use only and not intended for use in any public setting. A safety surface such as mulch or recycled tires should be used under the play set to prevent injury from falls. Also a 6 foot safety zone should be used around the entire play set.

As with any home project, good judgment and respect for power tools will greatly reduce the risk of injury. PlayNation recommends you follow all tool manufacturers' safety guidelines. Always wear eye protection and safety gloves to prevent injury. In several phases of construction two people may be required for lifting and securing of lumber. While play set is being constructed, please keep children off the equipment until the project is complete. Bolts and screw heads should be checked regularly for tightness. The ground ladder, rope ladder, slide, swings and other areas where children spend a majority of their playtime should be checked more frequently.

PlayNation shall not be liable for incidental, indirect or consequential damages or injuries that result from the building and/or playing on our play sets. Adult supervision is recommended anytime a play set is being used.

## WEIGHT LIMITS FOR PlayNation Play Systems

- DECK PLATFORMS: 800 LBS. TOTAL WEIGHT (This does not apply to bridge.)
- SWING BELTS: 225 LBS.
- GLIDER SWINGS: 70 LBS. PER CHILD UP TO 140 LBS TOTAL.
- TRAPEZE: 125 LBS.
- FULL BUCKET SWING: 50 LBS.
- HALF BUCKET SWING: 50 LBS.
- INFANT SWING: 35 LBS.
- TIRE SWING: 125 LBS. TOTAL WEIGHT
- ROPE LADDER: 75 LBS.
- CLIMBING RAMP: 150 LBS
- ROCK WALL: 150 LBS.
- SUPER SCOOP / SUPER WAVE SCOOP SLIDES: 250 LBS.
- SUPER TUBE SLIDE: 250 LBS.
- MONKEY BARS: 125 LBS.

PlayNation recommends that the weight limits for all components must not be exceeded. Failure to adhere to these and other safety guidelines could result in damage to the play set and injury to the users.

## Safety and Maintenance Tips for Your New Play Set:

**NOTE: Your children's safety is our #1 concern. Observing the following statements and warnings reduces the likelihood of serious or fatal injury. Please review these safety rules regularly with your children.**

- Each play set (Unit A and Unit C) is designed for the use of 4 occupants who have a combined weight not exceeding 800 pounds on the elevated decks. Unit B (Bridge) is designed for the use of 4 occupants who have a combined weight of 600 pounds total; 300 pounds on the swing area and 300 pounds on the bridge platform. This makes a total unit capacity of 12 occupants who have a combined weight of  $800 + 800 + 600 = 2200$  pounds. (This weight does not include the picnic table areas.)
- On-site adult supervision is required.
- Teach children not to walk close to, in front of, behind, or between moving swings or other moving playground equipment.
- Teach children to sit in and never stand on swings.
- Teach children not to twist the chains and ropes and not to loop them over the swing beam, since this may reduce the strength of the chain or rope.
- Teach children not to jump from swings or other playground equipment in motion.
- Teach children not to push empty seats. The seat may hit them and cause serious injury.
- Teach children to sit in the center of the swings with their full weight on the seats.
- Teach children not to use the equipment in a manner other than intended.
- Teach children to always go down slides feet first. Never slide headfirst.
- Teach children to look before they slide to make sure no one is at the bottom.
- Teach children to never run up a slide, as this increases their chances of falling.
- The parents should have the children dress appropriately with well-fitting shoes. Loose clothing such as scarves and ponchos should not be worn. Always take off, tie up or tuck in cords and drawstrings on children's clothing. These things can get caught on playground equipment and strangle a child.
- Teach children not to climb when the equipment is wet.
- Teach children to never jump from a fort deck. They should always use the ladder, ramp or slide.
- Teach children to never crawl or walk across the top of monkey bars.
- Teach children to never crawl on top of a fort or bridge roof.
- Verify that any suspended climbing ropes, chains, or cables are secured at both ends.
- Verify climbing ropes are tight enough that they cannot be wrapped around an adult hand.
- Teach children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
- Teach children to never wrap their legs around swing chain.
- Teach children to never slide down the swing chain.

**WARNING: Children must NOT use this play set until unit has been completely assembled and inspected by an adult to insure set has been properly installed.**

## Safety and Maintenance Tips for Your New Play Set: (continued)

Playgrounds should be inspected on a regular basis. If any of the following conditions are noted, they should be removed, corrected, or repaired immediately to prevent injuries.

- Hardware that is loose, worn or that has protrusions or projections.
- Exposed equipment footings.
- Scattered debris, litter, rocks, or tree roots.
- Splinters, large cracks, and decayed wood components.
- Deterioration and corrosion on structural components, which connect to the ground.
- Missing or damaged equipment components, such as handholds, guardrails, swing seats.
- Check all nuts and bolts frequently during the usage season and tighten as required. (But not so tight that you crack the wood) We recommend you check the swing beam and hardware often due to wood expansion and contraction. It is particularly important that this procedure be followed at the beginning of each season.
- Remove plastic swing seats and take indoors or do not use when the temperature drops below 32°F.
- Oil all metallic moving parts monthly during the usage period.
- Check all coverings for bolts and sharp edges twice monthly during usage season to be certain they are in place. Replace when necessary. It is especially important to do this at the beginning of each new season.
- Check swing seats, ropes, cables and chains monthly during usage season for evidence of deterioration. Replacement should be made of any swing seat that has developed cracks in the plastic seats. Ropes, cables and chains should be removed and replaced if excessive wear is found. Contact PlayNation for warranted replacement parts.
- For rusted areas on metallic members such as monkey bars, hand supports brackets, etc.; sand and repaint, using a non lead-based paint meeting the requirements of Title 16 CRF Part 1303.
- Inspect wood parts monthly. The grain of the wood sometimes will lift in the dry season causing splinters to appear. Light sanding may be necessary to maintain a safe playing environment. If you are treating your play set with stain regularly, it will help prevent severe checking/splitting and other weather damage.
- Once or twice a year, depending on your climate conditions, you must apply some type of protection (sealant) to the wood of your unit. Prior to the application of sealant, lightly sand any “rough” spots on your set. Please note this is a requirement of your warranty.
- Creating and maintaining the play set on a level location is very important. As your children play, your play set will slowly dig its way into the soil, and it is very important that it settles evenly. Make sure the play set is level and true once each year or at the beginning of each play season.
- Rake the playground surface periodically to prevent compaction and maintain appropriate depths.
- Disposal Instructions: When the play set is no longer desired, it should be disassembled and disposed of in such away that no unreasonable hazards will exist at the time the unit is discarded.



# Play Set Surfacing Recommendations:

Below are some of the recommendations that the U.S. Consumer Product Safety Commission (CPSC) offers from its *Handbook for Public Playground Safety*. The guide can be downloaded in full at [www.cpsc.gov/cpscpub/pubs/325.pdf](http://www.cpsc.gov/cpscpub/pubs/325.pdf)

**1. Protective Surfacing** - Since almost 60% of all injuries are caused by falls to the ground, protective surfacing under and around all playground equipment is the most critical safety factor on playgrounds.

Certain manufactured synthetic surfaces also are acceptable; however, test data on shock absorbing performance should be requested from the manufacturer.

Asphalt and concrete are unacceptable. They do not have any shock absorbing properties. Similarly, grass and turf should not be used. Their ability to absorb shock during a fall can be reduced considerably through wear and environmental conditions.

Certain loose-fill surfacing materials are acceptable such as the types and depths shown in the table.

## Fall Heights and Recommended Materials

Type Of Material	6 in. depth	9 in. depth	12 in. depth
Double-Shredded bark mulch	6' Fall Height	10' Fall Height	11' Fall Height
Wood Chips	6' Fall Height	7' Fall Height	12' Fall Height
Fine Sand	5' Fall Height	5' Fall Height	9' Fall Height
Shredded Tires*	10-12' Fall Height	n/a	n/a
Fine Gravel	6' Fall Height	7' Fall Height	10' Fall Height

\*This data is from tests conducted by independent testing laboratories on a 6-inch depth of uncompressed shredded tire samples produced by four manufacturers. The tests reported critical heights, which varied from 10 feet to greater than 12 feet. It is recommended that persons seeking to install shredded tires as a protective surface request test data from the supplier showing the critical height of the material when it was tested in accordance with ASTM F1292.

*It should be recognized that all injuries due to falls cannot be prevented no matter what surfacing material is used.*



**2. Fall Zones** - A fall zone, covered with a protective surfacing material, is essential under and around equipment where a child might fall. This area should be free of other equipment and obstacles onto which a child might fall. Stationary climbing equipment and slides should have a fall zone extending a Minimum of 6' in all directions from the perimeter of the equipment.

Swings should have a fall zone extending a minimum of 6' from the outer edge of the support structure on each side. The fall zone in front and back of the swing should extend out a minimum distance of twice the height of the swing as measured from the ground to the top of the swing support structure.

## Leveling Your Fort During Assembly


- Complete the steps which will be the basic frame of the fort {i.e. four corner posts with base (sand box boards) and deck supports}
- Position in the most level area chosen for the play set, keeping in mind the location and size of the swing beam, ladder, slides, etc. that extend off the fort.
- Once the frame is in the final position, check for vertical and horizontal levelness to determine which side(s) will need to be dug into the ground to level the play set.
- With a shovel, score the ground around the outside edges of the sandbox boards on the 'high' side of the fort. This is the area that will be dug in. Make sure to score deep enough; the scored lines will be your digging template.
- Push the frame off and away from the scored area, far enough to dig and remove dirt to reach the appropriate depth.
- Dig a channel along the scored line(s) for the base of the fort (corner post and sandbox boards) to rest into. Dig the channel(s) to the same level depth. The bottom of the channel(s) should be level to each other so your frame doesn't teeter or rock because the channel(s) are uneven.
- Once you have removed enough grass and dirt, slide/push the frame into the channel(s). Place a level on the vertical and horizontal boards of the frame to determine if enough soil, or too much, was removed.
- Repeat this process until the basic frame is plumb and level and in its final position before completing the rest of the assembly.
- Measure diagonally make sure fort is square.

**Important: if you require a channel depth of more than 6", then we recommend you have your play set area professionally graded before completing assembly.**



Top View of Playset Frame showing diagonal measurements.

THE DIAGONAL MEASUREMENTS SHOULD BE THE SAME FROM CORNER POST TO CORNER POST. IF NOT, ADJUST FORT SO THAT THE DISTANCE IS EQUAL.

 = AREA TO BE SCORED AND CHANNELLED FOR LEVELNESS

# General Info to Review Before Installation

- Depending on your experience, assembly of PlayNation Playsets can take as little as 6 hours up to 24 hours, depending on size, after inventory of parts; therefore, we recommend you set aside a full two days for assembly.
- Identify all of the parts for your play set. Empty each box and lay out boards so you can see each part. Your instruction book will have detailed drawings that will make it easy for you to recognize individual parts. Keep all hardware and metal parts separate from wooden pieces.
- After everything is laid out, check carefully to ensure all parts are present. Make sure there are no broken boards.
- Find an area to sort your hardware. It is best to open the hardware on a solid surface so that you do not lose any pieces in the grass. This will save time and familiarize you with all the different pieces in the hardware bag.
- Important note: Wood has some natural defects such as knots, surface cracks, etc... We reject parts that are structurally defective. We use a high quality lumber in our structures; however, you should inspect each part for splinters or rough spots and sand them smooth to prevent injury.
- After familiarizing yourself with all of the components, read all instructions thoroughly. Reading instructions after you have studied the parts will help you understand more clearly the installation process, and help to eliminate unnecessary mistakes.
- Pay close attention to the diameter and length of each bolt and screw.
- Never tighten hardware completely at first. It helps to have some adjustment for bolt alignment while you are attaching parts together. After everything is square, tighten each joint.
- After the main unit is assembled it is critical that the floor is **level** and **square**. If the main frame is not level, the walls and floor will be out of square.
- After you complete installation, make sure every bolt, screw, and nut is tight, and every board is secure. Wood will expand and contract with the seasons.
- Check all bolt connections and swing hangers seasonally.
- Place the set on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.

**This page is a list of definitions and explanations used throughout our instructions to aid you in the assembly of your play set.**

**Offset Holes-** Throughout the installation procedures we will refer to parts with offset holes. This refers to the orientation of the holes on the board. An offset hole is one that is closer to one side than it is to the other or in other words, it is not centered on the board. In the procedures you will be instructed to attach the boards with the holes “offset up” or with the holes “offset down”. This refers to which side of the board the hole/holes should be closer to. Offset Holes Up= hole/holes will be closer to the top of the board. Offset Holes Down= hole/holes will be closer to the bottom of the board. Note: some parts do not have offset holes, but instead the holes are on center. Therefore there will not be any reference to how to offset these parts.


### **EXAMPLE OF OFFSET HOLES UP**



### **EXAMPLE OF OFFSET HOLES DOWN**




**Counter-sunk holes-** Many of the parts that will be used have counter-sunk holes. A counter-sunk hole is one that surrounds one side of a thru hole, but does not extend through the wood itself. When using a counter-sunk hole the bolt will be inserted through the thru hole. In some cases the bolt head with a washer will occupy the counter-sunk hole. In other cases a nut with a washer will occupy the counter-sunk hole.



**Lag Screws-** Lag screws are used in the construction of our play sets to enhance the structural integrity of the unit. There will not be predrilled holes in the post for lag screw installation. Lag screws are self-tapping, though if you are using a manual socket wrench it may be necessary to tap the head of the lag screw with a hammer. You should also be sure to tighten the lag screws completely. Power tools such as an impact wrench or power drill should have enough torque to drive the lag screws without using a hammer, but make sure not to over tighten as this can cause the threads to “strip out” in the post.

**Please familiarize yourself with the manual, parts/components and general construction process of your new playset before getting started.**

### SITE PLAN:



**NOTE: ALL DIMENSIONS START AT THE SIDE OF THE CORNER POSTS.**

Playset height: 14 feet - 6 inches  
 Approximate assembly time: 24 hours  
**6 foot unobstructed safety perimeter around playset recommended.**

## REQUIRED TOOL LIST:

- \_\_\_ Standard or Cordless Drill w/ Phillips Bit (#2 square bit provided)
- \_\_\_ 1/8" Drill Bit
- \_\_\_ 3/8" Drill Bit
- \_\_\_ 1/2" Wrench and Socket
- \_\_\_ 1/2" Deep Well Socket
- \_\_\_ 9/16" Deep Well Socket
- \_\_\_ 9/16" Wrench and Socket
- \_\_\_ Level
- \_\_\_ Tape Measure
- \_\_\_ Extension Cord (if using standard drill)
- \_\_\_ Hammer
- \_\_\_ Pencil
- \_\_\_ Locking Pliers (Vise Grips)
- \_\_\_ Shovel
- \_\_\_ Carpenters Square

## KIT CONTENTS

### Swings, Slides, Accessories:

- \_\_\_ (Qty ) Description
- \_\_\_ (2) Swingbelts w/ Chains
- \_\_\_ (1) Trapeze Swing w/ Chains
- \_\_\_ (2) Super Scoop Slide (1 slide for 5ft deck, 1 slide for 7ft deck)
- \_\_\_ (1) Super Scoop Wave Slide
- \_\_\_ (1) Super Tube Slide
- \_\_\_ (2) Turbo Tire Swings w/ Chains
- \_\_\_ (1) Steering Wheel
- \_\_\_ (2) Telescope
- \_\_\_ (1) Periscope
- \_\_\_ (1) Dinner Bell
- \_\_\_ (2) Flag Kit (pair)
- \_\_\_ (1) Flower Box
- \_\_\_ (4) Plastic Safety Handles (pair)
- \_\_\_ (4) Metal Safety Handles
- \_\_\_ (1) Personalized Name Plate

### Play Set Hardware:

*See pages included for each unit.*

### Wood Components:


*See pages included for each unit.*




# **UNIT A**

**(LEFT SIDE UNIT as you are standing in front of play set looking at the front.)**


3/8" x 5"  
LAG SCREW  
QTY: 52




3/8" x 3-1/2"  
LAG SCREW  
QTY: 96




TORQUE  
WASHER  
QTY: 19




3/8" X 4-1/2"  
CARRIAGE BOLT  
QTY: 2





3/8" X 6-1/2"  
CARRIAGE BOLT  
QTY: 17



3/8" WASHER  
QTY: 167



1/4" WASHER  
QTY: 4



#14 X 1-1/4"  
PAN HEAD SCREW  
QTY: 7



#8 X 1-1/4"  
WOOD SCREW  
QTY: 18



#8 X 1-1/2"  
WOOD SCREW  
QTY: 146



#8 X 2"  
WOOD SCREW  
QTY: 178




#8 X 2-1/2"  
WOOD SCREW  
QTY: 32



#8 X 3"  
WOOD SCREW  
QTY: 2








3/8" LOCK NUT  
QTY: 19

















3/8" BOLT CAP  
QTY: 19



USE THE RULER TO THE RIGHT TO MEASURE YOUR BOLTS AND SCREWS. PICTURE VIEWS SHOWN ABOVE ARE 1:1 SCALE AND CAN BE USED TO MATCH BOLT AND SCREW SIZES.






PICTURE	DESCRIPTION	QTY.
	<p>1 x 4-1/2" x 70" ROOF STARTER (GROOVE ONLY)</p>	<p><b>2</b></p>
	<p>1 X 6" X 70" ROOF BOARD (TONGUE AND GROOVE)</p>	<p><b>17</b></p>
	<p>1 X 4-1/2" X 70" ROOF FINISHER (TONGUE ONLY)</p>	<p><b>1</b></p>
	<p>1 X 3-1/2" X 70" ROOF FINISHER (TONGUE ONLY)</p>	<p><b>1</b></p>
	<p>2 X 4 X 18" RAMP POST SUPPORT</p>	<p><b>4</b></p>
	<p>2 X 4 X 30-3/4" CL CENTER DECK SUPPORT</p>	<p><b>2</b></p>
	<p>2 X 4 X 34" PICNIC TABLE SUPPORT</p>	<p><b>4</b></p>








PICTURE	DESCRIPTION	QTY.
	<p>2 X 4 X 51" ROOF SUPPORT - RIGHT</p>	<p><b>2</b></p>
	<p>2 X 4 X 51" ROOF SUPPORT - LEFT</p>	<p><b>2</b></p>
	<p>2 X 4 X 70" CENTER DECK SUPPORT</p>	<p><b>2</b></p>
	<p>2 x 4 x 70" TOP PANEL BOARD (END HOLES OFFSET)</p>	<p><b>2</b></p>
	<p>2 X 4 X 70" SAFETY BOARD</p>	<p><b>1</b></p>
	<p>2 X 4 X 70" CL TOP PANEL BOARD (ALSO CALLED STEP FILLER BOARD ON TAG) (ALL HOLES OFFSET)</p>	<p><b>1</b></p>
	<p>2 X 6 X 16" SUN</p>	<p><b>2</b></p>









PICTURE	DESCRIPTION	QTY.
	2 X 6 X 62-3/4" PICNIC TABLE SEAT	<b>2</b>
	2 X 6 X 70" SANDBOX BOARD	<b>4</b>
	2 X 6 X 70" BOTTOM PANEL BOARD	<b>1</b>
	2 X 6 X 70" CL BOTTOM SPACER	<b>2</b>
	4 X 4 X 25" BLOCK	<b>8</b>
	4 X 4 X 30-3/4" CL DECK SUPPORT	<b>2</b>
	4 X 4 X 32-3/4" CL CENTER POST	<b>1</b>






PICTURE	DESCRIPTION	QTY.
	4 X 4 X 36" RAMP POST	<b>2</b>
	4 X 4 X 36-3/4" RAMP CROSS MEMBER	<b>1</b>
	4 X 4 X 37-3/8" CL CENTER POST	<b>1</b>
	4 X 4 X 43" CENTER POST	<b>1</b>
	4 X 4 X 53" CENTER LAG POST	<b>1</b>
	4 X 4 X 62-3/4" TIRE SWING SUPPORT	<b>1</b>
	4 X 4 X 70" BLOCK SUPPORT	<b>4</b>















PICTURE	DESCRIPTION	QTY.
	4 X 4 X 70" DECK SUPPORT	<b>2</b>
	4 X 4 X 70" LAG POST	<b>2</b>
	4 X 4 X 109-1/2" CORNER POST	<b>4</b>
	4 X 4 X 130-1/2" CL CORNER POST	<b>2</b>
	4 X 6 X 62-3/4" CL BOTTOM SPACER	<b>1</b>
	4 X 6 X 112" TRAPEZE ARM	<b>1</b>
	5/4 X 1-1/2" X 10" SMALL RAY	<b>12</b>

PICTURE	DESCRIPTION	QTY.
	5/4 X 1-1/2" X 16" LARGE RAY	<b>2</b>
	5/4 X 2" X 47-1/2" ROOF CENTER STRINGER	<b>1</b>
	5/4 X 2" X 50" ROOF CENTER STRINGER	<b>1</b>
	5/4 X 2-5/8" X 42" SUN SUPPORT	<b>2</b>
	5/4 X 3-1/2" X 29-3/4" DECK SPACER	<b>8</b>
	5/4 X 4" X 63-1/8" ROOF END CAP	<b>1</b>
	5/4 X 6 X 10-1/2" ROOF PEAK SUPPORT	<b>2</b>

PICTURE	DESCRIPTION	QTY.
	2-BOARD DECK PANEL 11-1/4" W X 69-1/2" L	<b>1</b>
	3-BOARD DECK PANEL 16-7/8" W X 69-1/2" L	<b>3</b>
	3-BOARD PICNIC TABLE 16-7/8" W X 69-1/2" L	<b>1</b>
	4-BOARD DECK PANEL 23-1/4" W X 69-1/2" L	<b>1</b>
	SIDE PANEL 70W X 32" H	<b>2</b>
	POST PANEL 70" W X 32" H	<b>1</b>
 	CL ROOF PEAK 3-1/2" X 3-1/2" X 73"	<b>1</b>

PICTURE	DESCRIPTION	QTY.
	<p>1 X 5 X 70" ROOF PEAK</p>	<p><b>1</b></p>
	<p>4-1/4"H X 27"L X 73"W CL ROOF SECTION</p>	<p><b>2</b></p>
	<p>DORMER (UNASSEMBLED)</p>	<p><b>1</b></p>
	<p>30" W X 25"H CL STEPS</p>	<p><b>2</b></p>
	<p>29-3/4" W X 120"L CLIMBING RAMP</p>	<p><b>1</b></p>

PICTURE	DESCRIPTION	QTY.
	TIRE SWIVEL	<b>1</b>
(NOT SHOWN)	1/2" X 15 FEET BLUE RAMP ROPE	<b>2</b>
	IRON DUCTILE SWING HANGER	<b>2</b>
	TELESCOPE	<b>1</b>
	FLAG KIT (PAIR)	<b>1</b>
	SUPER TUBE SLIDE	<b>1</b>
	METAL SAFETY HANDLE	<b>2</b>


PICTURE	DESCRIPTION	QTY.
	PLASTIC SAFETY HANDLES (PAIR)	<b>2</b>
	SCOOP SLIDE FOR 5FT DECK HEIGHT	<b>1</b>
	TIRE SWING WITH CHAINS	<b>1</b>
	SNAP HOOK	<b>5</b>
	TRAPEZE BAR WITH CHAINS	<b>1</b>
	PLAYNATION LOGO PLATE	<b>1</b>
		28



# STEP 1: CORNER POSTS

1: PLACE THE 2 X 6 X 70" SANDBOX BOARDS FLUSH WITH THE BOTTOM AND SIDES OF THE 4 X 4 X 109-1/2" CORNER POSTS. NOTE DIRECTION OF HOLES AT 51-1/2" OFF BOTTOM OF POSTS.


2: ATTACH THE SANDBOX BOARD (OFFSET UP) TO THE CORNER POSTS WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 2: BLOCK SUPPORTS

1: PLACE THE 4 X 4 X 70" BLOCK SUPPORTS FLUSH TO THE INSIDE OF THE CORNER POSTS, LINING UP THE PILOT HOLES. MAKE SURE THREE COUNTER-SUNK HOLES ARE FACING TO THE INSIDE OF THE UNIT. TWO COUNTER-SUNK HOLES SHOULD BE FACING DOWN.


2: FASTEN THE BLOCK SUPPORTS TO THE CORNER POSTS WITH 3/8" X 6-1/2" CARRIAGE BOLTS WITH TORQUE WASHERS ON THE OUTSIDE AND 3/8" NUTS WITH 3/8" WASHERS ON THE INSIDE. PLACE BOLT CAPS OVER EXPOSED THREADS.



## STEP 3: SANDBOX BOARDS

1: PLACE THE REMAINING 2 X 6 X 70" SANDBOX BOARDS FLUSH WITH THE BOTTOM OF THE CORNER POSTS.


2: FASTEN THE SANDBOX BOARDS TO THE CORNER POSTS WITH 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 4: DECK SUPPORTS

1: PLACE THE 4 X 4 X 70" DECK SUPPORTS FLUSH TO THE INSIDE OF THE CORNER POSTS, ON TOP OF THE BLOCK SUPPORTS.

2: FASTEN THE DECK SUPPORTS TO THE CORNER POSTS WITH 5" LAG SCREWS AND 3/8" WASHERS FROM THE INSIDE. FASTEN DECK SUPPORTS TO THE BLOCK SUPPORTS WITH 5" LAG SCREWS AND 3/8" WASHERS FROM UNDERNEATH.




## STEP 5: CENTER POSTS

1: PLACE THE 4 X 4 X 43" CENTER POST FLUSH WITH THE BOTTOM OF THE BLOCK SUPPORT ON THE FRONT OF THE PLAY SET, LINING UP THE PILOT HOLES AT THE CENTER OF THE BLOCK SUPPORT.

2: FASTEN THE 4 X 4 X 43" CENTER POST TO THE BLOCK SUPPORT WITH A 3/8" X 6-1/2" CARRIAGE BOLT WITH A TORQUE WASHER ON THE OUTSIDE, AND A 3/8" WASHER WITH A 3/8" LOCK NUT ON THE INSIDE. PLACE A BOLT CAP OVER EXPOSED THREADS.

3: PLACE THE 4 X 4 X 32-3/4" CENTER POST FLUSH WITH THE BOTTOM OF THE BLOCK SUPPORT ON THE REAR OF THE PLAY SET, LINING UP THE PILOT HOLES AT THE CENTER OF THE BLOCK SUPPORT.

2: FASTEN THE 4 X 4 X 32-3/4" CENTER POST TO THE BLOCK SUPPORT WITH A 3/8" X 6-1/2" CARRIAGE BOLT WITH A TORQUE WASHER ON THE OUTSIDE, AND A 3/8" WASHER WITH A 3/8" LOCK NUT ON THE INSIDE. PLACE A BOLT CAP OVER EXPOSED THREADS.




## STEP 6: TIRE SWING SUPPORT

1: PLACE THE 4 X 4 X 62-3/4" TIRE SWING SUPPORT FLUSH ON TOP OF THE BLOCK SUPPORTS, IN LINE WITH THE CENTER POSTS. NO SCREWS ARE NEEDED FOR THE TIRE SWING SUPPORT.


2: PLACE THE 2 X 4 X 70" CENTER DECK SUPPORTS FLUSH AGAINST THE CENTER POSTS, ON TOP OF THE BLOCK SUPPORTS. FASTEN THE CENTER DECK SUPPORTS TO THE CENTER POSTS AND THE TIRE SWING BEAM WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.

NOTE: THE HOLES OF THE CENTER DECK SUPPORTS ARE OFFSET UP ON ONE SIDE AND OFFSET DOWN ON THE OTHER SIDE.



## STEP 7: BLOCKS AND TIRE SWIVEL

- 1: PLACE FOUR 4 X 4 X 25" BLOCKS FLUSH ON TOP OF THE BLOCK SUPPORTS, BETWEEN THE CENTER AND END DECK SUPPORTS. FASTEN THE BLOCKS TO THE BLOCK SUPPORTS WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.
- 2: CENTER THE TIRE SWIVEL ON TOP OF THE 4 X 4 X 62-3/4" TIRE SWING SUPPORT.
- 3: MARK THROUGH THE BOLT HOLES OF THE TIRE SWIVEL ONTO THE TIRE SWING SUPPORT.
- 4: REMOVE THE TIRE SWIVEL FROM THE TOP OF THE TIRE SWING SUPPORT.
- 5: DRILL TWO 3/8" PILOT HOLES ON THE MARKS.
- 6: MOUNT THE TIRE SWIVEL TO THE BOTTOM OF THE TIRE SWING SUPPORT WITH TWO 3/8" X 4-1/2" CARRIAGE BOLTS WITH TWO TORQUE WASHERS ON TOP, AND TWO 3/8" NUTS WITH TWO 3/8" WASHERS ON BOTTOM. USE BOLT CAPS TO COVER ANY EXPOSED THREADS.







# PLAYSET SPACING FOR BRIDGE


1: AT THIS STAGE OF CONSTRUCTION YOU HAVE BUILT **UNIT A** THROUGH STEP 7. STUDY THE NEXT PAGE AS WELL. SKIP TO **UNIT C** ON PAGE 105 AND BUILD **UNIT C** UP THROUGH STEP 7.

2: ALL THE REAR CORNER POSTS SHOULD BE IN A STRAIGHT LINE AS SHOWN IN THE **TOP VIEW** BELOW. AND THE UNITS SHOULD BE LEVEL TO ONE ANOTHER UP AND DOWN AS SHOWN IN THE **FRONT VIEW** BELOW.

3: THE REAR AND FRONT CORNER POSTS SHOULD BE 103" FROM INSIDE TO INSIDE AS SHOWN.



# PLAYSET SPACING FOR BRIDGE




## STEP 8: DECK PANELS

1: PLACE THE DECK PANELS ACROSS THE DECK SUPPORTS. ALLOW THE 2 X 4 DECK STRINGERS TO OVERLAP THE DECK SUPPORTS. PLACE THE DECK PANELS FLUSH WITH THE CORNER POSTS. FOR THE DECK PANELS IN THE CENTER SPACE THEM APPROXIMATELY 7/16" FROM ONE ANOTHER.

THE END OF EACH DECK PANEL SHOULD BE FLUSH OR TOWARD THE INSIDE 3/16" FROM THE SIDE FACE OF THE CORNER POSTS.


2: ATTACH EACH DECK BOARD TO THE DECK SUPPORTS WITH TWO 2" WOOD SCREWS WHERE THEY OVERLAP.



## STEP 9: DECK SPACERS


1: PLACE THE 5/4 X 3-1/2 X 29 3/4" DECK SPACERS FLUSH ON TOP OF THE CENTER AND END DECK SUPPORTS, BETWEEN THE CENTER AND CORNER POSTS.

2: FASTEN THE DECK SPACERS TO THE CENTER AND END DECK SUPPORTS WITH TWO 2" WOOD SCREWS AT EACH END.




## STEP 10: SIDE PANEL

PLACE THE 70" SIDE PANEL FLUSH AGAINST THE CORNER POSTS ON THE LEFT SIDE OF THE FORT, ALLOWING THE PANEL BOARDS TO REST ON TOP OF THE DECK. FASTEN THE SIDE PANEL TO THE CORNER POSTS USING 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 11: SIDE PANEL

PLACE THE 70" SIDE PANEL FLUSH AGAINST THE CORNER POSTS ON THE RIGHT SIDE OF THE FORT, ALLOWING THE PANEL BOARDS TO REST ON TOP OF THE DECK. FASTEN THE SIDE PANEL TO THE CORNER POSTS USING 3-1/2" LAG SCREWS AND 3/8" WASHERS.






## STEP 12: SAFETY BOARDS

1: PLACE THE 2 X 4 X 70" TOP PANEL BOARD (END HOLES OFFSET UP) FLUSH TO THE FRONT CORNER POSTS AND FLUSH TO THE TOPS OF THE SIDE PANELS. FASTEN THE TOP PANEL BOARD TO THE FRONT, CENTER, AND CORNER POSTS WITH 3-1/2" LAG SCREWS AND 3/8" WASHERS.

2: PLACE THE 2 X 4 X 70" SAFETY BOARD FLUSH TO THE CORNER POSTS ON THE RIGHT SIDE OF THE FORT, AT 24". FASTEN THE SAFETY BOARD TO THE CORNER POSTS WITH 3-1/2" SCREWS AND 3/8" WASHERS






## STEP 13: CLIMBING RAMP


1: PLACE THE BOTTOM OF THE 4 X 4 X 36-3/4" RAMP CROSS-MEMBER FLUSH WITH THE BOTTOM OF THE 4 X 4 X 36" RAMP POSTS. EACH END OF THE RAMP CROSS-MEMBER SHOULD BE FLUSH WITH THE SIDE OF EACH RAMP POST.

2: FASTEN EACH 4 X 4 X 36" RAMP POST TO THE 4 X 4 X 36-3/4" RAMP CROSS-MEMBER WITH A 3/8" X 5" LAG SCREW AND A 3/8" WASHER.



## STEP 14: CLIMBING RAMP


- 1: PLACE THE RAMP ASSEMBLY ON TOP OF THE RAMP CROSS-MEMBER.
- 2: ALIGN THE COUNTER-SUNK HOLES WITH THE CENTER OF THE RAMP POSTS.
- 3: FASTEN THE RAMP ASSEMBLY TO THE RAMP POSTS WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS FROM THE INSIDE OF THE RAMP ASSEMBLY.



## STEP 15: CLIMBING RAMP

1: PLACE THE 2 X 4 X 18" RAMP POST SUPPORTS ON TOP OF THE 2 X 4 RAMP RAIL. ALIGN THE END OF THE RAMP POST SUPPORT WITH CENTER OF THE RAMP POST SIDE.


2: FASTEN THE RAMP POST SUPPORTS TO THE RAMP POSTS WITH 2-1/2" WOOD SCREWS FROM THE INSIDE, AND TO THE 2 X 4 RAMP RAIL FROM THE TOP.




## STEP 16: CLIMBING RAMP

1: PLACE THE CLIMBING RAMP FLUSH TO THE INSIDE OF THE FRONT CENTER POST AND LEFT CORNER POST. CENTER THE COUNTERSUNK HOLES AT THE END OF THE RAMP WITH THE CENTER OF THE FRONT CENTER POST AND LEFT CORNER POST.

2: FASTEN THE CLIMBING RAMP TO THE FRONT CENTER POST AND LEFT CORNER POST USING 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS IN THE COUNTERSUNK HOLES AT THE END OF THE RAMP.




DETAIL A  
SCALE 1 : 8



## STEP 17: CLIMBING RAMP

1: DRILL 3/4" PILOT HOLES THROUGH THE FRONT OF THE LEFT FRONT CORNER POST, AND CENTER POST.

2: THREAD A PIECE OF 1/2" DIAMETER X 15 FOOT ROPE THROUGH THE HOLES, STARTING AT THE HOLE IN THE PLAY SET POSTS. TIE A SECURE KNOT IN THE ROPE AT BOTH ENDS TO HOLD THE ROPE IN PLACE.






## STEP 18: BOTTOM PANEL BOARD

1: ALIGN THE 2 X 6 X 70" BOTTOM PANEL BOARD WITH THE BOTTOM 2 X 6 BOARDS OF THE SIDE PANELS.


2: FASTEN THE BOTTOM PANEL BOARD TO THE REAR CORNER POSTS WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 19: LAG POSTS

1: PLACE THE 4 X 4 X 70" LAG POSTS ON TOP OF THE BOTTOM PANEL BOARD, FLUSH AGAINST THE REAR CORNER POSTS. FASTEN THE LAG POSTS TO THE REAR CORNER POSTS WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.

2: PLACE THE 4 X 4 X 53" CENTER LAG POST ON TOP OF THE BOTTOM PANEL BOARD, FLUSH AGAINST THE REAR CENTER POST. FASTEN THE CENTER LAG POST TO THE REAR CENTER POST WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.






## STEP 20: CL DECK SUPPORTS

1: PLACE THE 4 X 4 X 30-3/4" CL DECK SUPPORTS ON THE INSIDE OF THE CORNER LAG POSTS, LINING UP THE PILOT HOLES, WITH THE COUNTER-SUNK HOLES FACING THE CENTER POST.


2: FASTEN THE CL DECK SUPPORTS TO THE CORNER LAG POSTS USING 6-1/2" CARRIAGE BOLTS WITH TORQUE WASHERS AND 3/8" NUTS WITH 3/8" WASHERS. PLACE BOLT CAPS OVER ANY EXPOSED THREADS.



## STEP 21: CL CORNER POSTS

1: PLACE THE 4 X 4 X 130-1/2" CL CORNER POSTS ON THE OUTSIDE OF THE CL DECK SUPPORTS, LINING UP THE PILOT HOLES.


2: FASTEN THE CL CORNER POSTS TO THE CL DECK SUPPORTS USING 6-1/2" CARRIAGE BOLTS WITH TORQUE WASHERS AND 3/8" NUTS WITH 3/8" WASHERS. PLACE BOLT CAPS OVER ANY EXPOSED THREADS.



## STEP 22: CL BOTTOM SPACERS

1: PLACE THE 4 X 6 CL BOTTOM SPACER IN BETWEEN THE CL CORNER POSTS. NO SCREWS ARE NEEDED.


2: PLACE THE 2 X 6 X 70" BOTTOM SPACER ON BOTH SIDES OF THE 4 X 6 BOTTOM SPACER AND SECURE TO THE CL CORNER POSTS WITH 3-1/2" LAG SCREWS AND 3/8" WASHERS. THE HOLES IN THE ENDS OF THE 2 X 6 X 70" BOTTOM SPACER SHOULD BE OFFSET UP ON ONE SIDE OF THE 4 X 6 CL BOTTOM SPACER AND THE HOLES SHOULD BE OFFSET DOWN ON THE OTHER SIDE OF THE 4 X 6 CL BOTTOM SPACER.



## STEP 23: BLOCK SUPPORTS

1: PLACE THE 4 X 4 X 70" BLOCK SUPPORT UNDERNEATH THE CL DECK SUPPORTS AND IN FRONT OF THE CL LAG POSTS WITH THE COUNTER-SUNK HOLES FACING DOWN AND FACING THE BACK OF THE UNIT.(SEE NOTE BELOW). FASTEN THE BLOCK SUPPORT TO THE THREE LAG POSTS WITH THREE 5" LAG SCREWS AND THREE 3/8" WASHERS. FROM UNDERNEATH FASTEN THE BLOCK SUPPORT TO THE 4 X 4 X 30-3/4" CL DECK SUPPORTS WITH TWO 5" LAG SCREWS AND TWO 3/8" WASHERS.

2: PLACE THE 4 X 4 X 70" BLOCK SUPPORT UNDERNEATH THE CL DECK SUPPORTS AND IN FRONT OF THE CL CORNER POSTS WITH THE COUNTER-SUNK HOLES FACING DOWN AND FACING TOWARD THE FRONT OF THE UNIT.(SEE NOTE BELOW). FASTEN THE BLOCK SUPPORT TO THE CL CORNER POSTS WITH TWO 5" LAG SCREWS AND TWO 3/8" WASHERS. FROM UNDERNEATH FASTEN THE BLOCK SUPPORT TO THE 4 X 4 X 30-3/4" CL DECK SUPPORTS WITH TWO 5" LAG SCREWS AND TWO 3/8" WASHERS.






## STEP 24: CL CENTER POST


1: PLACE THE 4 X 4 X 37-3/8" CL CENTER POST AGAINST THE BLOCK SUPPORT AND LINE UP THE PILOT HOLES.

2: FASTEN THE CL CENTER POST TO THE BLOCK SUPPORT WITH 6-1/2" CARRIAGE BOLTS WITH TORQUE WASHER AND 3/8" NUT WITH 3/8" WASHER. PLACE A BOLT CAP OVER ANY EXPOSED THREADS.




## STEP 25: CL CENTER DECK SUPPORTS

PLACE THE 2 X 4 X 30-3/4" CL CENTER DECK SUPPORTS ON TOP OF THE BLOCK SUPPORTS AND AGAINST THE CENTER POSTS. FASTEN THE CL CENTER DECK SUPPORT TO THE CENTER POSTS WITH 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 26: BLOCKS

- 1: PLACE THE 4 X 4 X 25" BLOCKS ON TOP OF THE BLOCK SUPPORTS BETWEEN THE CL CENTER AND END DECK SUPPORTS. THE COUNTERSUNK HOLES SHOULD FACE UP.
- 2: FASTEN THE BLOCKS TO THE BLOCK SUPPORTS WITH 5" LAG SCREWS AND 3/8" WASHERS.






## STEP 27: CL DECK PANEL

1: PLACE THE 4 BOARD DECK ACROSS THE DECK SUPPORTS, ALLOWING THE 2 X 3 DECK STRINGERS TO OVERLAP THE DECK SUPPORTS.


2: ATTACH EACH DECK BOARD WITH TWO 2" WOOD SCREWS WHERE IT OVERLAPS A DECK SUPPORT. EACH DECK BOARD WILL GET ATTACHED TO THE DECK SUPPORTS WITH EIGHT SCREWS TOTAL.



## STEP 28: DECK SPACERS

1: PLACE THE 5/4 X 3-1/2 X 29-3/4" DECK SPACERS ON TOP OF THE CL CENTER AND END DECK SUPPORTS, BETWEEN THE CL CORNER AND CENTER POSTS.


2: FASTEN EACH DECK SPACER TO THE CL CENTER AND END DECK SUPPORTS WITH TWO 2" WOOD SCREWS ON EACH END.



## STEP 29: CL STEPS


1: PLACE THE CL STEPS BETWEEN THE BACK CENTER AND CORNER POSTS OF THE FORT, ALLOWING THE STEPS TO REST ON THE DECK.

2: FASTEN THE CL STEPS TO THE CENTER AND CORNER POSTS WITH 5" LAG SCREWS AND 3/8" WASHERS FROM THE INSIDE OF THE CL STEP RAIL SIDE 4 X 4'S.



## STEP 30: POST PANEL

1: PLACE THE POST PANEL ON THE CL CORNER POSTS, ALLOWING THE PANEL BOARDS TO REST ON THE DECK. FASTEN THE POST PANEL TO THE CL CORNER POSTS WITH 3-1/2" LAG SCREWS AND 3/8" WASHERS






## STEP 31: PICNIC TABLE SUPPORTS

1: PLACE THE 2 X 4 X 34" PICNIC TABLE SUPPORTS AT 15" AND 28" (MEASURED FROM BOTTOM OF SANDBOX BOARD TO BOTTOM OF TABLE SUPPORTS) AGAINST THE CL AND BACK CORNER POSTS.


2: FASTEN THE PICNIC TABLE SUPPORTS TO THE POSTS WITH 3-1/2" LAG SCREWS AND 3/8" WASHERS



## STEP 32: PICNIC TABLE SEATS

1: PLACE THE 2 X 6 X 62-3/4" PICNIC TABLE SEATS ACROSS THE BOTTOM PICNIC TABLE SUPPORTS, BETWEEN THE CL AND BACK CORNER POSTS.

2: FASTEN THE PICNIC TABLE SEATS TO THE PICNIC TABLE SUPPORTS WITH 2-1/2" WOOD SCREWS.






## STEP 33: PICNIC TABLE

1: PLACE THE PICNIC TABLE ACROSS THE TOP PICNIC TABLE SUPPORTS, CENTERED BETWEEN THE CL AND BACK CORNER POSTS, ALLOWING THE PICNIC TABLE STRINGERS TO OVERLAP THE TOP PICNIC TABLE SUPPORTS.

2: FASTEN THE PICNIC TABLE TO THE PICNIC TABLE SUPPORTS WITH 2-1/2" WOOD SCREWS.





# STEP 34: MARKING/DRILLING CORNER POSTS

1: CLIMB UP ON TOP OF THE LOWER DECK OF THE PLAYSET AND FACE THE RIGHT SIDE OF THE PLAYSET. THE RAMP WILL BE TO YOUR RIGHT AND THE UPPER LEVEL WILL BE ON YOUR LEFT. (SEE FIGURE 1)


2: (SEE DETAIL A BELOW) MEASURE DOWN 1" FROM THE TOP OF THE CORNER POST ON YOUR LEFT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST  $1\frac{13}{16}$ " AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A  $\frac{1}{4}$ " DIAMETER HOLE  $2\frac{1}{2}$ " DEEP.

3: (SEE DETAIL B BELOW) MEASURE DOWN 1" FROM THE TOP OF THE CORNER POST ON YOUR RIGHT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST  $1\frac{13}{16}$ " AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A  $\frac{1}{4}$ " DIAMETER HOLE  $2\frac{1}{2}$ " DEEP.

4: TURN AROUND AND FACE THE LEFT SIDE OF THE PLAYSET. THE RAMP WILL BE TO YOUR LEFT NOW AND THE UPPER LEVEL WILL BE ON YOUR RIGHT (SEE FIGURE 2)

5: (SEE DETAIL C BELOW) MEASURE DOWN 1" FROM THE TOP OF THE CORNER POST ON YOUR LEFT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST  $1\frac{13}{16}$ " AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A  $\frac{1}{4}$ " DIAMETER HOLE  $2\frac{1}{2}$ " DEEP.

6: (SEE DETAIL D BELOW) MEASURE DOWN 1" FROM THE TOP OF THE CORNER POST ON YOUR RIGHT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST  $1\frac{13}{16}$ " AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A  $\frac{1}{4}$ " DIAMETER HOLE  $2\frac{1}{2}$ " DEEP.




# STEP 35: ROOF SUPPORT ASSEMBLIES

1: LOCATE TWO 2 X 4 X 51" ROOF SUPPORT (LEFT), TWO 2 X 4 X 51" ROOF SUPPORT (RIGHT) AND TWO 5/4 X 6 X 10-1/2" ROOF PEAK SUPPORT PIECES.

2: FIND A FLAT SURFACE TO WORK ON. LAY THE TRIANGLE SHAPED ROOF PEAK SUPPORT ON THE FLAT SURFACE. PLACE ONE ROOF SUPPORT (LEFT) AND ONE ROOF SUPPORT (RIGHT) ON TOP OF THE ROOF PEAK SUPPORT WITH THE COUNTERSUNK HOLES FACING UP. THE EDGES SHOULD BE FLUSH WHERE SHOWN BELOW.

3: USE FOUR #8 X 2" WOOD SCREWS TO ATTACH THE ROOF SUPPORTS TO THE ROOF PEAK SUPPORT AS SHOWN BELOW.

4: MAKE ONE MORE ROOF SUPPORT ASSEMBLY BY REPEATING 2 AND 3.




## STEP 36: ROOF SUPPORTS (LOWER DECK)

1: PLACE THE TWO ROOF SUPPORT ASSEMBLIES ON THE LOWER DECK.

2: ATTACH ONE ROOF SUPPORT ASSEMBLY TO THE HOLES YOU PREVIOUSLY DRILLED IN THE RIGHT SIDE CORNER POSTS WITH TWO 3/8" X 3-1/2" LAG SCREWS AND TWO 3/8" WASHERS. NOTE THAT THE TRIANGLE SHAPED ROOF PEAK SUPPORT WILL BE ON THE OUTSIDE .

3: ATTACH THE OTHER ROOF SUPPORT ASSEMBLY TO THE HOLES YOU PREVIOUSLY DRILLED IN THE LEFT SIDE CORNER POSTS WITH TWO 3/8" X 3-1/2" LAG SCREWS AND TWO 3/8" WASHERS. NOTE THAT THE TRIANGLE SHAPED ROOF PEAK SUPPORT WILL BE ON THE OUTSIDE .




## STEP 37: ROOF STARTERS

1: LOCATE TWO 1 X 4-1/2" X 70" ROOF STARTERS.




2: POSITION THE STARTERS AT THE ROOF PEAK SO THAT THE BOARDS ARE ALMOST TOUCHING. (SEE DETAIL A)

3: THE ROOF STARTERS WILL OVERHANG THE ROOF SUPPORTS BY APPROXIMATELY 3-7/16" ON EACH SIDE. (SEE "REAR VIEW" AT TOP RIGHT BELOW)


4: FASTEN THE ROOF STARTERS TO THE ROOF SUPPORTS WITH #8 X 1-1/2" WOOD SCREWS. (FOUR IN EACH BOARD) (SEE DETAIL B)



DETAIL A  
SCALE 1 : 10




DETAIL B  
SCALE 1 : 16






## STEP 38: ROOF PEAK

- 1: PLACE THE 1 X 5 X 70" ROOF PEAK ASSEMBLY ON TOP OF THE ROOF STARTERS.
- 2: ALIGN THE END OF THE ROOF PEAK ASSEMBLY FLUSH TO THE END OF THE ROOF STARTERS.
- 3: ATTACH THE ROOF PEAK ASSEMBLY TO THE ROOF STARTERS WITH EIGHT 1-1/4" WOOD SCREWS. (FOUR SCREWS PER SIDE)




DETAIL A  
SCALE 1 : 16




## STEP 39: ROOF BOARDS

- 1: LOCATE SEVENTEEN 1 X 6 X 70" ROOF BOARDS (TONGUE AND GROOVE).
- 2: SLIDE THE TONGUE OF ONE ROOF BOARD INTO THE GROOVE OF THE ROOF STARTER AND ALIGN THE ENDS SO THEY ARE FLUSH. IF NECESSARY USE A SCRAP 2 X 4 BLOCK AND A RUBBER Mallet TO SEAT THE TONGUE INTO THE GROOVE OF THE PREVIOUS BOARD.
- 3: ATTACH THE ROOF BOARD TO THE ROOF SUPPORTS WITH FOUR #8 X 1-1/2" WOOD SCREWS.
- 4: SLIDE THE TONGUE OF ANOTHER ROOF BOARD INTO THE GROOVE OF THE PREVIOUS ROOF BOARD. ATTACH THE ROOF BOARD TO THE ROOF SUPPORTS WITH FOUR #8 X 1-1/2" WOOD SCREWS. REPEAT THIS PROCESS FOR THE REMAINING ROOF BOARDS.
- 5: REPEAT SUBSTEPS 1-4 FOR THE OTHER SIDE OF THE ROOF. NOTE THE FRONT ROOF SECTION WILL RECEIVE NINE ROOF BOARDS WHILE THE REAR ROOF SECTION WILL RECEIVE EIGHT ROOF BOARDS.



DETAIL A  
SCALE 1 : 25





## STEP 40: ROOF END CAP


1: LOCATE ONE 5/4 X 4 X 63-1/8" ROOF END CAP.

2: PLACE THE ROOF END CAP AGAINST THE END OF THE ROOF SUPPORTS ON THE FRONT OF THE PLAY SET. MAKE SURE THE TOP OF THE ROOF END CAP AND THE TOP OF THE ROOF SUPPORTS ARE FLUSH.

3: ATTACH THE ROOF END CAP TO THE ROOF SUPPORTS WITH FOUR #8 X 2" WOOD SCREWS.

NOTE: THERE IS NO ROOF END CAP ON THE REAR ROOF SECTION.

5/4 X 4 X 63-1/8" ROOF END CAP




DETAIL A  
SCALE 1 : 16

NOTE THERE IS  
NO ROOF END CAP  
HERE.

ROOF  
END CAP

FRONT OF  
PLAY SET



## STEP 41: ROOF FINISHERS

1: LOCATE ONE 1 X 4-1/2" X 70" ROOF FINISHER.

2: ON THE FRONT ROOF SECTION:

PLACE THE TONGUE OF THE ROOF FINISHER INTO THE GROOVE OF THE LAST ROOF BOARD. MAKE SURE THE END OF THE ROOF FINISHER IS FLUSH WITH THE END OF THE ROOF BOARD.


3: ATTACH THE ROOF FINISHER TO THE ROOF SUPPORTS WITH FOUR #8 X 1-1/2" WOOD SCREWS.

4: LOCATE ONE 1 X 3-1/2" X 70" ROOF FINISHER.


5: ON THE REAR ROOF SECTION:

PLACE THE TONGUE OF THE ROOF FINISHER INTO THE GROOVE OF THE LAST ROOF BOARD. MAKE SURE THE END OF THE ROOF FINISHER IS FLUSH WITH THE END OF THE ROOF BOARD.

6: ATTACH THE ROOF FINISHER TO THE ROOF SUPPORTS WITH FOUR #8 X 1-1/2" WOOD SCREWS.



DETAIL A  
SCALE 1 : 24



## STEP 42: ROOF CENTER STRINGERS


1: LOCATE ONE 5/4 X 2" X 50" ROOF CENTER STRINGER AND ONE 5/4 X 2" X 47-1/2" ROOF CENTER STRINGER.

2: PLACE THE 50" ROOF CENTER STRINGER ON THE INSIDE OF THE FRONT ROOF SECTION. CENTER IT WITH THE ROOF BOARDS AND MAKE THE LOWER END FLUSH TO THE INSIDE OF THE ROOF END CAP.

3: ATTACH THE 50" ROOF CENTER STRINGER TO EACH ROOF BOARD WITH #8 X 1-1/2" WOOD SCREWS. EACH ROOF BOARD WILL BE ATTACHED TO THE STRINGER WITH TWO WOOD SCREWS.


4: PLACE THE 47-1/2" ROOF CENTER STRINGER ON THE INSIDE OF THE REAR ROOF SECTION. CENTER IT WITH THE ROOF BOARDS AND MAKE THE LOWER END FLUSH WITH THE ROOF FINISHER.

5: ATTACH THE 47-1/2" ROOF CENTER STRINGER TO EACH ROOF BOARD WITH #8 X 1-1/2" WOOD SCREWS. EACH ROOF BOARD WILL BE ATTACHED TO THE STRINGER WITH TWO WOOD SCREWS.




## STEP 43: SUNBURST

1: PRE-DRILL HOLES IN THE 2 X 6 X 16" SUN TO THE PATTERN SHOWN BELOW.




2: PLACE THE 2 X 6 X 16" SUN CENTERED AGAINST THE 5/4 X 2-5/8 X 42" SUN SUPPORT. FASTEN THE SUN TO THE SUN SUPPORT WITH 2" WOOD SCREWS. REPEAT THIS PROCESS ONE MORE TIME.





## STEP 44: SUNBURST

- 1: PLACE THE ASSEMBLY MADE IN THE PREVIOUS STEP UNDERNEATH THE ROOF BOARDS, AND AGAINST THE ANGLED ROOF SUPPORTS. MAKE SURE THE ASSEMBLY IS LEVEL BEFORE PROCEEDING TO THE NEXT STEP.
- 2: FASTEN THE SUN ASSEMBLY TO THE FORT WITH 2" WOOD SCREWS FROM THE OUTSIDE INTO THE ROOF SUPPORTS.
- 3: REPEAT ON THE OPPOSITE SIDE OF THE FORT.



## STEP 45: SUNBURST


1: PREDRILL ALL SUNRAYS 1/8" DIAMETER AT 3/4" ON CENTER FROM EACH END.

2: CENTER THE 5/4 X 1-1/2 X 16" LARGE RAY ONTO THE HALF SUN AND THE ROOF SUPPORT BOARDS AND FASTEN WITH TWO 1-1/2" SCREWS.

3: EQUALLY SPACE THE SMALL RAYS ABOUT THE HALF SUN (THREE ON EACH SIDE OF LARGE RAY) AND MARK THE POSITION OF THE SMALL SUNRAYS WITH A PENCIL.

4: SECURE THE SMALL SUNRAYS ONE AT A TIME TO THE HALF SUN AND THE ROOF SUPPORT BEAMS AND LINE THEM UP WITH THE MARK DRAWN. FASTEN THE SMALL SUNRAYS WITH TWO 1-1/2" WOOD SCREWS EACH. REPEAT ON OTHER SIDE OF FORT.

NOTE:  
ROOF BOARDS REMOVED FROM VIEW FOR CLARITY





## STEP 46: DORMER

- 1: ASSEMBLE THE DORMER ACCORDING TO THE INSTRUCTIONS INCLUDED WITH IT.
- 2: PLACE THE DORMER ON THE ROOF WITH THE FRONT EDGE EVEN WITH THE THIRD BOARD UP FROM THE BOTTOM.
- 3: ATTACH THE DORMER TO THE ROOF ACCORDING TO THE INSTRUCTIONS.




# STEP 47: TOP PANEL BOARDS

1: SEE FIGURE A: PLACE THE 2 X 4 X 70" TOP PANEL BOARD (OFFSET UP) AGAINST THE LAG POSTS ON THE UPPER LEVEL DECK. MAKE THE TOP OF THE TOP PANEL BOARD EVEN WITH THE TOP OF THE POST PANEL RAILING. NOTE THE TOP PANEL BOARD HAS END HOLES THAT ARE OFFSET AND A MIDDLE HOLE THAT IS CENTERED.

2: ATTACH THE TOP PANEL BOARD WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.

3: SEE FIGURE B: PLACE THE 2 X 4 X 70" CL TOP PANEL BOARD (OFFSET UP) DIRECTLY IN FRONT OF THE CL STEPS. NOTE THE CL TOP PANEL BOARD HAS THREE HOLES THAT ARE ALL OFFSET.

4: ATTACH THE CL TOP PANEL BOARD WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 48: CL ROOF CORNER POST HOLES

1: ON THE OUTSIDE OF THE RIGHT SIDE UPPER LEVEL CORNER POSTS YOU WILL NEED TO DRILL TWO HOLES. (SEE FIGURE 1)

2: (SEE DETAIL A BELOW) MEASURE DOWN 1-1/4" FROM THE TOP OF THE CORNER POST ON YOUR LEFT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST 1-7/8" AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A 1/4" DIAMETER HOLE 2-1/2" DEEP.

3: (SEE DETAIL B BELOW) MEASURE DOWN 1-1/4" FROM THE TOP OF THE CORNER POST ON YOUR RIGHT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST 1-7/8" AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A 1/4" DIAMETER HOLE 2-1/2" DEEP.

4: NOW GO TO THE OUTSIDE OF THE LEFT SIDE UPPER LEVEL CORNER POSTS. YOU WILL NEED TO DRILL TWO HOLES IN THE LEFT SIDE UPPER LEVEL CORNER POSTS ALSO. (SEE FIGURE 2)

5: (SEE DETAIL C BELOW) MEASURE DOWN 1-1/4" FROM THE TOP OF THE CORNER POST ON YOUR LEFT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST 1-7/8" AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A 1/4" DIAMETER HOLE 2-1/2" DEEP.

6: (SEE DETAIL D BELOW) MEASURE DOWN 1-1/4" FROM THE TOP OF THE CORNER POST ON YOUR RIGHT HAND SIDE AND MAKE A MARK. MEASURE OVER FROM THE OUTSIDE EDGE OF THE CORNER POST 1-7/8" AND MAKE A MARK. WHERE THE MARKS INTERSECT DRILL A 1/4" DIAMETER HOLE 2-1/2" DEEP.






FIGURE 1  
RIGHT SIDE VIEW

FIGURE 2  
LEFT SIDE VIEW



## STEP 49: CL ROOF PANELS


- 1: LOCATE TWO 27"W X 73"L CL ROOF PANELS.
- 2: ATTACH THE CL ROOF PANELS TO THE HOLES YOU JUST DRILLED IN THE CORNER POSTS WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.
- 3: THE MITERED END OF EACH PANEL SHOULD MEET TO FORM A RIGHT ANGLE AT THE PEAK OF THE ROOF.
- 4: CONNECT THE ROOF PANELS TOGETHER WITH TWO #8 X 3" WOOD SCREWS. DRIVE EACH SCREW THROUGH THE ROOF BOARD AND THEN THROUGH THE ROOF SUPPORT INTO THE OTHER ROOF SUPPORT. (SEE DETAIL A BELOW)



## STEP 50: CL ROOF PEAK

1: PLACE THE 3-1/2 X 3-1/2 X 73" CL ROOF PEAK ON TOP AT THE PEAK OF THE CL ROOF PANELS. MAKE THE END OF THE PEAK FLUSH TO THE ENDS OF THE ROOF PANELS.



2: ATTACH THE ROOF PEAK TO THE PANELS WITH EIGHT #8 X 1-1/4" WOOD SCREWS.



# STEP 51: TRAPEZE ARM ASSEMBLY

1: LOCATE THE 4 X 6 X 112" TRAPEZE ARM.

2: ATTACH TWO IRON DUCTILE SWING HANGERS UNDERNEATH THE TRAPEZE ARM WITH 3/8" X 6-1/2" CARRIAGE BOLTS AND TORQUE WASHERS ON TOP AND 3/8" WASHERS, 3/8" LOCK NUTS ON THE BOTTOM. COVER ANY EXPOSED THREADS WITH BOLT CAPS.





## STEP 52: TRAPEZE ARM INSTALLATION

1: PLACE THE TRAPEZE ARM ABOVE THE 2 X 4 ON THE FRONT OF THE PLAY SET AS SHOWN BELOW.

2: CENTER THE HOLES IN THE TRAPEZE ARM OVER THE CORNER POSTS.



3: HAVE AN ASSISTANT HOLD THE TRAPEZE ARM IN PLACE. USE THE HOLES IN THE TRAPEZE ARM TO DRILL TWO 3/8" DIAMETER HOLES THROUGH THE LEFT AND RIGHT CORNER POSTS. **DO NOT DRILL A HOLE IN THE CENTER POST.**

YOU MAY HAVE TO SPOT DRILL THE CORNER POSTS AND THEN REMOVE THE TRAPEZE ARM TO COMPLETE THE DRILLING PROCESS.


4: IF YOU REMOVED THE TRAPEZE ARM, PLACE IT BACK INTO POSITION. (SEE DETAIL A) ATTACH THE LEFT AND RIGHT HOLES OF THE TRAPEZE ARM TO THE CORNER POSTS WITH 3/8" X 6-1/2" CARRIAGE BOLTS AND TORQUE WASHERS ON THE INSIDE AND 3/8" WASHERS AND 3/8" LOCK NUTS ON THE OUTSIDE. PLACE BOLT CAPS OVER ANY EXPOSED THREADS.

5: (SEE DETAIL B) SECURE THE CENTER HOLE OF THE TRAPEZE ARM TO THE CENTER POST WITH A 3/8" X 5" LAG SCREW AND A 3/8" WASHER.

ONLY DRILL HOLES THROUGH LEFT AND RIGHT CORNER POSTS. **DO NOT DRILL CENTER POST.**



DETAIL A  
SCALE 1 : 16




DETAIL B  
SCALE 1 : 16

## STEP 53: TELESCOPE

1: PLACE THE TELESCOPE BASE CENTERED ON TOP OF THE CENTER POST AT THE FRONT OF THE PLAY SET.

2: PLACE ONE OF THE HALF CIRCLE SHAPED BRACKETS AROUND THE BASE OF THE TELESCOPE. SECURE THE BRACKET TO THE CENTER POST WITH THE SCREWS PROVIDED.


3: PLACE THE OTHER HALF CIRCLE SHAPED BRACKET AROUND THE BASE OF THE TELESCOPE DIRECTLY ACROSS FROM THE OTHER HALF CIRCLE SHAPED BRACKET. SECURE THE BRACKET TO THE CENTER POST WITH THE SCREWS PROVIDED.





## STEP 54: FLAGS

- 1: PLACE THE BASE OF EACH FLAG ON THE FRONT FACE OF THE TRAPEZE ARM.
- 2: ATTACH THE BASE TO THE TRAPEZE ARM WITH THE 1/2" PHILLIPS PAN HEAD SCREWS PROVIDED WITH THE FLAG.
- 3: INSERT THE MAST OF THE FLAG INTO THE FLAG BASE.




## STEP 55: SUPER TUBE SLIDE

1: ASSEMBLE THE SUPER TUBE SLIDE ACCORDING TO THE DIRECTIONS PROVIDED WITH THE SLIDE.

2: THE BOTTOM OF THE OPENING IN THE ENTRY SECTION SHOULD BE APPROXIMATELY FLUSH TO THE UPPER LEVEL DECK.

3: ATTACH THE SUPER TUBE ENTRY SECTION TO THE CORNER POSTS ON THE LEFT SIDE OF THE UPPER LEVEL USING THE HARDWARE DESCRIBED IN THE SUPER TUBE DIRECTIONS.






## STEP 56: METAL SAFETY HANDLES

1: PLACE A METAL SAFETY HANDLE CENTERED ON THE FRONT LEFT CORNER POST AND FRONT CENTER POST ABOVE THE RAMP.

2: LOCATE THE HANDLES UP OR DOWN TO SUIT THE NEEDS OF YOUR CHILD.


3: ATTACH EACH METAL HANDLE TO THE POST WITH 1/4" FLAT WASHERS AND #14 X 1-1/4" PAN HEAD SCREWS.






## STEP 57: PLASTIC SAFETY HANDLES

- 1: PLACE EACH PLASTIC SAFETY HANDLE CENTERED ON THE INSIDE FACE OF THE POSTS SHOWN BELOW.
- 2: ADJUST EACH HANDLE UP OR DOWN TO SUIT THE NEEDS OF YOUR CHILD.
- 3: ATTACH EACH SAFETY HANDLE TO THE POST WITH TWO PAN HEAD SCREWS AND TWO WASHERS PROVIDED WITH THE SAFETY HANDLES.




DETAIL A  
SCALE 1 : 8




## STEP 58: 5' SCOOP SLIDE

- 1: PLACE THE 5' SCOOP SLIDE IN THE OPENING AT THE RIGHT FRONT OF THE PLAY SET.
- 2: THE NOTCHED AREA UNDER THE SLIDE SHOULD BE FLUSH TO THE FRONT AND TOP SURFACES OF THE DECK SPACER.
- 3: ATTACH THE SCOOP SLIDE TO THE DECK SPACER WITH THREE #14 X 1-1/4" PAN HEAD SCREWS.




## STEP 59: TIRE SWING

- 1: LOCATE THE TIRE SWING WITH CHAINS ATTACHED TO IT. LOCATE THREE SNAP HOOKS.
- 2: SNAP EACH SNAP HOOK OVER ONE CHAIN ON THE TIRE SWING.
- 3: SNAP EACH SNAP HOOK OVER THE EYELET ON THE TIRE SWIVEL.
- 4: ADJUST THE CHAIN UP OR DOWN BY UNSNAPPING THE SNAP HOOK FROM THE CHAIN, RELOCATE THE CHAIN UP OR DOWN AND HOOK THE CHAIN OVER THE SNAP HOOK. REPEAT FOR THE REMAINING SNAP HOOKS AND CHAINS.
- 5: IF THE CHAIN IS TOO LONG YOU MAY LOOP IT AND SNAP EACH LOOP OVER THE SNAP HOOK. OR YOU MAY CUT THE EXCESS CHAIN OFF IF YOU WISH.




DETAIL A  
SCALE 1 : 8





## STEP 60: HANG TRAPEZE

- 1: LOCATE THE TRAPEZE BAR WITH THE CHAINS ATTACHED AND TWO SNAP HOOKS.
- 2: SNAP THE SNAP HOOKS OVER THE LOOPS ON THE SWING HANGERS.
- 3: SNAP THE END OF EACH CHAIN OVER THE SNAP HOOKS AS SHOWN.
- 4: IF NECESSARY ADJUST THE CHAINS UP TO SUIT THE NEEDS OF YOUR CHILD BY CLIPPING THE CHAINS HIGHER ON THE SNAP HOOKS. ANY EXCESS CHAIN CAN BE LOOPED AND CLIPPED ONTO THE SNAP HOOKS OR IT CAN BE CUT OFF.



## STEP 61: LOGO PLATE

1: PLACE THE PLAYNATION LOGO PLATE ONTO THE TRAPEZE ARM COVERING THE CENTER HOLE.

2: ATTACH THE LOGO PLATE WITH TWO #8 X 1-1/4" WOOD SCREWS.



FASTEN WITH  
TWO 1-1/4"  
WOOD SCREWS.

DETAIL A  
SCALE 1 : 4

TRAPEZE ARM

PLAYNATION  
LOGO PLATE





**NOW SKIP TO STEP 8**  
**FOR UNIT C ON PAGE 114.**


# UNIT C

**(RIGHT SIDE UNIT as you are standing in front of play set looking at the front.)**

#14 X 1-1/4"  
PAN HEAD SCREW  
QTY: 3



#8 X 1"  
PAN HEAD SCREW  
QTY: 4



#8 X 1-1/4"  
WOOD SCREW  
QTY: 16




#8 X 1-1/2"  
WOOD SCREW  
QTY: 30




#8 X 2"  
WOOD SCREW  
QTY: 218




#8 X 2-1/2"  
WOOD SCREW  
QTY: 20




3/8 x 6-1/2"  
CARRIAGE BOLT  
QTY: 12



3/8 x 4-1/2"  
CARRIAGE BOLT  
QTY: 8




3/8 x 5"  
HEX LAG SCREW  
QTY: 54




3/8 x 3-1/2"  
HEX LAG SCREW  
QTY: 103



3/8 LOCK NUT  
QTY: 20




TORQUE WASHER  
QTY: 20











3/8 WASHER  
QTY: 189











PLASTIC  
BOLT CAP  
QTY: 20










USE THE RULER TO THE RIGHT TO MEASURE YOUR BOLTS AND SCREWS. PICTURE VIEWS SHOWN ABOVE ARE 1:1 SCALE AND CAN BE USED TO MATCH BOLT AND SCREW SIZES.


PICTURE	DESCRIPTION	QTY.
	5/4 X 1 1/2 X 16 1/2" SUNBURST PIECE	8
	5/4 X 1 1/2 X 23 1/2" SUNBURST PIECE	2
	5/4 X 3 1/2 X 29 3/4" DECK SPACER	6
	5/4 X 3 1/2 X 62 3/4" DECK SPACER	2
	5/4 X 6 X 29" PANEL SLATS	4
	2 X 4 X 27 1/2" TOP PORCH PANEL BOARD	2
	2 X 4 X 30 3/4" CL-CENTER DECK SUPPORT	2
	2 X 4 X 30 3/4" CL-TOP PANEL BOARD	1








PICTURE	DESCRIPTION	QTY.
	2 X 4 X 34" PICNIC TABLE SUPPORT	4
	2 X 4 X 70" SAFETY BOARD	1
	2 X 4 X 70" TOP PANEL BOARD	1
	2 X 4 X 94" CENTER DECK SUPPORTS	2
	2 X 6 X 24" BOTTOM PANEL BOARD	2
	2 X 6 X 62 3/4" PICNIC TABLE SEAT	2
	2 X 6 X 70" BACK STARTER BOARD	2
	2 X 6 X 70" FILLER BOARD	1








PICTURE	DESCRIPTION	QTY.
	2 X 6 X 70" SANDBOX/FILLER BOARD	4
	2 X 6 X 94" SANDBOX BOARD (1 LEFT 1 RIGHT)	2
	4 X 4 X 25" BLOCK	10
	4 X 4 X 30 3/4" CL-DECK SUPPORT	2
	4 X 4 X 43" CL-CENTER POST	1
	4 X 4 X 43" CENTER POST	1
	4 X 4 X 53" CL-CENTER LAG POST	1






PICTURE	DESCRIPTION	QTY.
	4 X 4 X 58" CL-CENTER POST	1
	4 X 6 X 63" CL-BOTTOM SPACER	1
	4 X 4 X 70" PORCH BLOCK SUPPORTS	1
	4 X 4 X 70" FORT BLOCK SUPPORTS	4
	4 X 4 X 71" CL-LAG POST	2
	4 X 4 X 75" ROPE LADDER RUNNER	1
	4 X 4 X 90 1/2" TIRE SWING SUPPORT	1





PICTURE	DESCRIPTION	QTY.
	4 X 4 X 94" DECK SUPPORTS	2
	4 X 4 X 113 1/2" PORCH POST	2
	4 X 4 X 123 1/2" CORNER POST	4
	4 X 4 X 131" CL-CORNER POST	2
	4 X 6 X 112" ROPE LADDER SUPPORT	1
	PRE ASSEMBLED 11 1/4 X 69 1/2" 2-BOARD DECK	1
	PRE ASSEMBLED 16 7/8 X 69 1/2" 3-BOARD DECK/ PICNIC TABLE	4









PICTURE	DESCRIPTION	QTY.
	PRE ASSEMBLED 20 1/4" X 69 1/2" 3 1/2-BOARD DECK	1
	PRE ASSEMBLED 23" X 69 1/2" 4-BOARD DECK	1
	PRE ASSEMBLED SUNBURST PIECE	2
	UNASSEMBLED DORMER	1
	PRE ASSEMBLED PORCH ROOF	1
	PRE ASSEMBLED FORT ROOF PANEL	2
	PRE ASSEMBLED CL-PORCH ROOF PANEL WITH THE FASCIA HOLE AT 4 1/2"	1

PICTURE	DESCRIPTION	QTY.
	PRE-ASSEMBLED CL-PORCH ROOF PANEL WITH THE FASCIA HOLE AT 5 3/4"	1
	1 X 5 X 73" ROOF PEAK	1
	PRE ASSEMBLED DOOR	1
	PRE ASSEMBLED SIDE WALL PANEL	2
	PRE ASSEMBLED FULL DOOR WALL PANEL	1



PICTURE	DESCRIPTION	QTY.
	<p>PRE ASSEMBLED 70" X 30 3/4" CL-PORCH POST PANEL</p>	<p>1</p>
	<p>PRE ASSEMBLED FLOWER BOX</p>	<p>1</p>
	<p>PRE ASSEMBLED 25" X 30 " CL-STEPS</p>	<p>2</p>
	<p>PRE ASSEMBLED 5 STEP LADDER</p>	<p>1</p>
	<p>ROPE LADDER ASSEMBLY</p>	<p>1</p>


PICTURE	DESCRIPTION	QTY.
	SUPER SCOOP WAVE SLIDE	1
	14' SCOOP SLIDE	1
	TIRE SWING WITH CHAINS	1
	PLASTIC SAFETY HANDLES (PAIR)	2
	METAL SAFETY HANDLES	2

PICTURE	DESCRIPTION	QTY.
	TIRE SWING SWIVEL	1
	SPRING CLIPS	3
	28-0001 BRACKET	1
	PLASTIC FLAG KIT	2
	DINNER BELL	1
	STEERING WHEEL	1
	TELESCOPE	1
	NAME PLATE	1

## STEP 1: SANDBOX BOARDS


1. PLACE THE 2 X 6 X 94" RIGHT SANDBOX BOARD (HOLES OFFSET DOWN) FLUSH WITH THE BOTTOM OF TWO 4 X 4 X 123 1/2" CORNER POSTS AND ONE 4 X 4 X 113 1/2" PORCH POST. ALL COUNTERSUNK HOLES FACE INWARD. CENTER ALL POSTS WITH THE HOLES ON THE SANDBOX BOARD. FASTEN THE SANDBOX BOARD TO POST WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.
2. REPEAT THIS STEP USING THE 2 X 6 X 94" LEFT SANDBOX BOARD (HOLES OFFSET DOWN).

NOTE: MAKE SURE THE COUNTERSUNK HOLES IN THE CORNER POSTS ARE TO THE INSIDE LAY FLAT ON GROUND FOR EASIER ASSEMBLY



## STEP 2: FORT/PORCH BLOCK SUPPORT


1. PLACE TWO 4 X 4 X 70" FORT BLOCK SUPPORTS WITH 4 HOLES (THE 2 INSIDE COUNTERSUNK HOLES FACE DOWN AND THE 2 OUTSIDE COUNTERSUNK HOLES FACE IN) TO THE CORNER POSTS AT THE 51.5" HOLES. FASTEN THE BLOCK SUPPORTS FROM THE OUTSIDE WITH 3/8" X 6 1/2" CARRIAGE BOLTS AND TORQUE WASHERS THEN 3/8" WASHERS AND 3/8" LOCKNUTS FROM THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS.
2. PLACE THE 4 X 4 X 70" PORCH BLOCK SUPPORT WITH 5 HOLES FLUSH TO THE PORCH POST FOLLOWING THE INSTRUCTIONS ABOVE.






## STEP 3: SANDBOX/FILLER BOARDS

1. PLACE THREE 2 X 6 X 70" SANDBOX/FILLER BOARDS (HOLES OFFSET UP) FLUSH WITH THE BOTTOM OF THE CORNER POSTS AND PORCH POSTS, AS SHOWN BELOW. FASTEN THE SANDBOX/FILLER BOARDS WITH 3/8" X 3 1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 4: DECK SUPPORTS


1. PLACE THE 4 X 4 X 94" DECK SUPPORTS ON TOP OF THE FORT/BLOCK SUPPORTS. FASTEN THE DECK SUPPORTS TO THE CORNER POSTS WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.
2. FASTEN THE DECK SUPPORTS TO THE FORT/BLOCK SUPPORTS WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS FROM UNDERNEATH.



# STEP 5: CENTER POST, TIRE SWING SUPPORT & SAFETY BOARD


1. PLACE THE 4 X 4 X 43" CENTER POST AT THE CENTER HOLE ON THE PORCH BLOCK SUPPORT. FASTEN FROM THE OUTSIDE WITH 3/8" X 6 1/2" CARRIAGE BOLTS AND TORQUE WASHERS THEN A 3/8" WASHERS WITH 3/8" LOCKNUT ON THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS.
2. PLACE THE 4 X 4 X 90 1/2" TIRE SWING SUPPORT FLUSH ON TOP OF THE BLOCK SUPPORTS, IN LINE WITH THE CENTER POSTS. FASTEN WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.
3. FLUSH THE 2 X 4 X 70" SAFETY BOARD TO THE TWO CORNER POST ON THE LEFT SIDE. PLACE A DISTANCE OF 24" FROM THE BOTTOM OF THE SANDBOX BOARD TO THE BOTTOM OF SAFETY BOARD. FASTEN WITH 3/8" X 3 1/2" LAG SCREWS AND 3/8" WASHER.

SIDE VIEW




## STEP 6: CENTER DECK SUPPORTS

1. PLACE THE 2 X 4 X 94" CENTER DECK SUPPORTS FLUSH AGAINST THE CENTER POSTS, ON TOP OF THE FORT BLOCK SUPPORTS. MAKE SURE THE COUNTERSUNK HOLES ON ONE CENTER DECK SUPPORT ARE OFFSET UP ON ONE SIDE AND ARE OFFSET DOWN ON THE OTHER SIDE. FASTEN THE CENTER DECK SUPPORTS TO THE CENTER POST AND TIRE SWING BEAM WITH 3/8 X 3 1/2" LAG SCREWS WITH 3/8" WASHERS.



## STEP 7: TIRE SWIVEL AND BLOCK SUPPORTS

1. CENTER THE TIRE SWIVEL BETWEEN THE FORT BLOCK SUPPORTS ON THE TIRE SWING SUPPORT. MARK THE BOLT HOLES OF THE SWIVEL. DRILL TWO 3/8" PILOT HOLES THROUGH THE TIRE SWING SUPPORT. MOUNT THE SWIVEL WITH 3/8" x 4 1/2" CARRIAGE BOLT AND TORQUE WASHER FROM THE TOP AND 3/8" WASHER AND 3/8" LOCKNUT ON BOTTOM. USE BOLT CAPS TO COVER ALL EXPOSED THREADS. ATTACH THE TIRE SWING TO THE TIRE SWIVEL WITH SPRING CLIPS. ONE SPRING CLIP PER CHAIN WILL BE USED TO ATTACH THE CHAINS TO THE ROUND EYE ON THE TIRE SWIVEL.
2. PLACE THE 4 X 4 X 25" BLOCKS (COUNTERSUNK HOLES FACE UP) ON TOP OF THE FORT AND PORCH BLOCK SUPPORTS, BETWEEN THE CENTER DECK SUPPORTS AND DECK SUPPORTS. FASTEN THE BLOCKS TO THE BLOCK SUPPORTS WITH 3/8" x 5" LAG SCREWS AND 3/8" WASHERS.







# PLAYSET SPACING FOR BRIDGE

1: AT THIS STAGE OF CONSTRUCTION YOU HAVE BUILT **UNIT A AND UNIT C** THROUGH STEP 7. STUDY THE NEXT PAGE AS WELL.


2: ALL THE REAR CORNER POSTS SHOULD BE IN A STRAIGHT LINE AS SHOWN IN THE **TOP VIEW** BELOW. AND THE UNITS SHOULD BE LEVEL TO ONE ANOTHER UP AND DOWN AS SHOWN IN THE **FRONT VIEW** BELOW.

3: THE REAR AND FRONT CORNER POSTS SHOULD BE 103" FROM INSIDE TO INSIDE AS SHOWN.

4: LEVEL AND SQUARE EACH UNIT INDIVIDUALLY AS DESCRIBED IN THE FRONT OF THE MANUAL. RECHECK THE 103" DIMENSION AND MAKE SURE THE UNITS ARE LEVEL TO ONE ANOTHER. GO TO STEP 8 ON PAGE 38 FOR **UNIT A** AND COMPLETE CONSTRUCTION OF **UNIT A**.




# PLAYSET SPACING FOR BRIDGE




## STEP 8: ASSEMBLY OF LOWER DECK

1. PLACE PRE-ASSEMBLED DECK BOARD SECTIONS ON TOP OF DECK SUPPORTS, AS SHOWN BELOW. BE SURE THEY ARE EVENLY SPACED. CONTINUE TO STEP 9 FOR COMPLETION OF DECK.




## STEP 9: COMPLETION OF LOWER DECK

1. PLACE THE TWO 5/4 X 3 1/2 X 62 3/4" DECK SPACER BOARDS ACROSS THE TOP OF THE DECK SUPPORTS BETWEEN THE CORNER POSTS, AS SHOWN BELOW.
2. PLACE THE (2) 5/4 X 3 1/2 X 29 3/4" DECK SPACER BOARDS ACROSS THE TOP OF THE DECK SUPPORTS AND CENTER DECK SUPPORTS BETWEEN THE PORCH POSTS AND CENTER POST, AS SHOWN BELOW.
3. MAKE SURE THE PRE-ASSEMBLED DECKS AND DECK SPACERS ARE EVENLY SPACED AND CENTERED. SECURE WITH TWO 2" WOOD SCREWS TO DECK SUPPORT ON EACH DECK BOARD.



## STEP 10: LADDER & SAFETY HANDLES


1. REST LADDER ON GROUND THEN ANGLE LADDER SO THAT THE COUNTER SUNK HOLES ARE CENTERED ON THE PORCH POST AND THE CENTER POST. ATTACH THE LADDER WITH TWO 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.
2. CENTER THE METAL SAFETY HANDLES ON THE PORCH POST AND THE CENTER POST, ADJUST HANDLES UP OR DOWN FOR DESIRED HEIGHT TO SUIT THE NEEDS OF YOUR CHILD. ATTACH THE HANDLES WITH THE HARDWARE PROVIDED.






## STEP 11: SIDE WALL PANELS

1. PLACE PRE-ASSEMBLED SIDE WALL PANELS FLUSH WITH CORNER POSTS, ALLOWING PANEL BOARDS TO REST ON DECK. BE SURE THAT COUNTERSUNK HOLES OFFSET UP ON TOP BOARD AND OFFSET DOWN ON BOTTOM BOARD OF WALL ASSEMBLY. FASTEN WITH  $3/8 \times 3 \frac{1}{2}$ " LAG SCREWS AND  $3/8$ " WASHERS.




## STEP 12: ROOF PANELS

1. PLACE ROOF PANEL (WITH MISSING BOARDS) WITH 45° END FACING TOWARD THE INSIDE OF FORT, LET REST ON CORNER POST AND WALL PANEL. FASTEN THE ROOF SUPPORT TO THE CORNER POST FROM THE OUTSIDE WITH 3/8 X 4 1/2" CARRIAGE BOLTS AND TORQUE WASHERS AND 3/8" WASHERS WITH 3/8" LOCKNUTS ON THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS. DO NOT TIGHTEN BOLTS COMPLETELY AT THIS TIME.
2. REPEAT STEP WITH SECOND ROOF PANEL THAT IS NOT MISSING ROOF BOARDS. CONTINUE TO STEP 13 FOR COMPLETION OF ROOF.



## STEP 13: COMPLETION OF ROOF


1. AFTER BOTH ROOF PANELS ARE FASTENED, RAISE ROOF PANELS AT CENTER OF FORT UNTIL THE 45° ANGLES COME TOGETHER TO MAKE A PEAK. FASTEN THE TWO ROOF SUPPORTS TOGETHER WITH 2 1/2" WOOD SCREWS, PERPENDICULAR AT THE MITER JOINTS, AS SHOWN BELOW. TIGHTEN BOLTS AT THE ROOF SUPPORT AND CORNER POST.
2. PLACE ROOF PEAK ON TOP OF ROOF, FLUSH WITH ROOF PANELS. FASTEN ROOF PEAK TO ROOF WITH 1 1/4" WOOD SCREWS, FOUR IN EACH SIDE, CENTERED AND EVENLY SPACED AS SHOWN BELOW.



## STEP 14: LOWER SUNBURST

1. PLACE THE LOWER PRE-ASSEMBLED SUNBURST PIECE ABOVE THE WALL PANEL ON INSIDE AND FLUSH AGAINST THE ROOF FRAME. FASTEN WITH 2" WOOD SCREWS TO THE WALL PANEL AND ROOF FRAME, AS SHOWN BELOW.
2. REPEAT STEP TO COMPLETE OTHER SIDE.


NOTE: ROOF OMITTED FOR CLARITY.



## STEP 15: UPPER SUNBURST

1. PREDRILL A 1/8" HOLE 1" FROM EACH END AND CENTERED ON EACH RAY USING THE PATTERN SHOWN BELOW.
2. PLACE THE 5/4 X 1 1/2 X 23 1/2" SUNBURST PIECE (RAY) FLUSH AGAINST THE PEAK OF THE ROOF FRAME AND CENTERED ON THE HALF CIRCLE . FASTEN WITH 1 1/2" WOOD SCREWS TO THE ROOF SUPPORTS AND SUN, AS SHOWN BELOW.  
PLACE THE 5/4 X 1 1/2 X 16 1/2" SUNBURST PIECES (RAYS) FLUSH AGAINST THE ROOF FRAME, SPACED EQUALLY AND ANGLED TO THE HALF CIRCLE . FASTEN WITH 1 1/2" WOOD SCREWS TO THE ROOF SUPPORTS AND SUN, AS SHOWN BELOW.
2. REPEAT STEP TO COMPLETE OTHER SIDE.

NOTE: ROOF OMITTED FOR CLARITY.






## STEP 16: DOOR WALL PANEL

1. PLACE DOOR WALL PANEL FLUSH ON CORNER POSTS, ALLOWING WALL PANEL BOARDS TO REST ON DECK. BE SURE THAT COUNTERSUNK HOLES OFFSET DOWN ON TOP BOARD OF WALL PANEL ASSEMBLY. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS. FASTEN THE BOTTOM CORNER OF THE DOOR PANEL TO THE FLOOR ON THE INSIDE OF THE PLAY HOUSE WITH A 28-0001 BRACKET AND #8 X 1" PHILLIPS PAN HEAD SCREWS AS SHOWN IN THE TOP RIGHT PICTURE BELOW.
2. PLACE THE 2 X 6 X 70" FILLER BOARD (COUNTERSUNK HOLES OFFSET DOWN) FLUSH WITH CORNER POST AND WALL ASSEMBLY. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.


NOTE: ROOF AND WALL OMITTED FOR CLARITY.



## STEP 17: DOOR


1. PLACE DOOR INSIDE OF FORT. FLUSH DOOR WITH CORNER POST AND FRONT WALL ASSEMBLY UPPER BOARD. PLACE A 1/2" WOOD PIECE UNDER DOOR FOR STABILITY. FASTEN HINGES TO INSIDE OF FRONT CORNER POST WITH 1 1/2" WOOD SCREWS. DOOR WILL OPERATE WITH AN IN-SWING OPENING.

NOTE: ROOF AND SIDE PANEL OMITTED FOR CLARITY



## STEP 18: DORMER


1. USE THE INSTRUCTIONS PROVIDED TO BUILD AND INSTALL THE DORMER. CENTER DORMER ON FRONT ROOF PANEL WITH FRONT OF DORMER FLUSH WITH THE BOTTOM OF THE THIRD SLAT OF ROOF PANEL, AS SHOWN BELOW.



## STEP 19: PORCH ROOF PANELS


1. PLACE FRONT ROOF PANEL ON FRONT ROOF AND ON TOP OF PORCH POSTS WITH 45° END FACING INWARD. FASTEN THE ROOF SUPPORTS TO PORCH POST WITH 3/8 X 4 1/2" CARRIAGE BOLTS AND TORQUE WASHERS FROM THE OUTSIDE AND 3/8" WASHERS WITH 3/8" LOCKNUTS ON THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS.
2. FASTEN BACK OF PORCH ROOF TO FRONT ROOF WITH 2 1/2" WOOD SCREWS, AS SHOWN BELOW.

NOTE: TWO ROOF BOARDS ARE OMITTED FOR CLARITY.




## STEP 20: FRONT PORCH PANELS

1. STARTING AT ONE SIDE OF THE FRONT PORCH, FLUSH THE 2 X 6 X 24" BOTTOM PANEL BOARD (HOLES OFFSET DOWN) WITH THE PORCH POST AND WITH THE BOTTOM FORT PANEL BOARD ON SIDE WALL PANEL. TOP OF BOTTOM PORCH PANEL AND TOP OF BOTTOM FORT PANEL BOARDS SHOULD BE EVEN. FASTEN TO PORCH POST WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS. THEN FASTEN TWO 2 1/2" WOOD SCREWS EVENLY SPACED AND UP 2" FROM BOTTOM OF THE 2 X 6 X 24" BOTTOM PANEL BOARD, AS SHOWN IN THE EXAMPLE BELOW.
2. FROM THE INSIDE, PLACE THE BOTTOM OF THE TWO 5/4 X 6 X 29" PANEL SLATS ON TOP OF THE DECK, EVENLY SPACED BETWEEN THE PORCH POST AND THE CORNER POST. FASTEN WITH 2" WOOD SCREWS TO THE BOTTOM PORCH PANEL.
3. FLUSH THE 2 X 4 X 27 1/2" TOP PANEL BOARD WITH THE PORCH POST AND CORNER POST AND WITH THE TOP OF THE PANEL SLATS. FASTEN TO THE POST WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS. FROM THE INSIDE FASTEN THE TOP OF THE PANEL SLATS TO THE TOP PANEL BOARD WITH 2" WOOD SCREWS.
4. REPEAT STEPS 1-3 ON OTHER SIDE OF PORCH.




EXAMPLE FOR PLACEMENT OF SCREWS ON 2 X 6 X 24" BOTTOM PANEL BOARD






## STEP 21: TOP PANEL BOARD

1. FLUSH THE 2 X 4 X 70" TOP PANEL BOARD (HOLES OFFSET DOWN) WITH THE TWO PORCH POST AND CENTER POST. THE TOP OF THE TOP PANEL BOARD AND TOP OF TOP PORCH PANEL BOARD SHOULD BE EVEN. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.




## STEP 22: CL-CENTER POST

1. PLACE THE 2 X 6 X 70" FILLER BOARD (COUNTERSUNK HOLES OFFSET UP) FLUSH AGAINST THE BACK CORNER POSTS, AT THE SAME HEIGHT AS THE BOTTOM BOARD ON THE SIDE WALL PANELS. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.
2. PLACE THE 4 X 4 X 58" CL-CENTER POST IN LINE WITH THE CENTER HOLES OF THE 2 X 6 X 70" FILLER BOARD AND REST THE POST ON TOP OF THE DECK. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.




## STEP 23: CL-STEPS

1. PLACE ONE PRE-ASSEMBLED CL-STEP BETWEEN THE CL-CENTER POST AND THE CORNER POST, FLUSH WITH FILLER BOARD AND REST ON LOWER DECK. FASTEN WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.
2. REPEAT STEP 1 FOR THE SECOND CL-STEP




## STEP 24: CL-CORNER & CL-CENTER LAG POST

1. PLACE THE 4 X 4 X 70" CL-CORNER LAG POSTS FLUSH AGAINST THE FORT'S BACK CORNER POSTS AND ON TOP OF THE 2 X 6 X 70" FILLER BOARD. FASTEN WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.
2. PLACE THE 4 X 4 X 53" CL-CENTER LAG POST FLUSH AGAINST CL-CORNER POST AND ON TOP OF THE 2 X 6 X 70" FILLER BOARD. FASTEN THE CL-CENTER LAG POST TO THE CL-CORNER POST WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS.



## STEP 25: CL-DECK SUPPORTS


1. PLACE THE 4 X 4 X 30 3/4" CL-DECK SUPPORTS (COUNTERSUNK HOLES FACE INWARD) FLUSH WITH THE INSIDE OF THE CL-CORNER LAG POSTS, LINING UP THE HOLES, AS SHOWN BELOW. FASTEN FROM THE OUTSIDE OF THE CL-CORNER LAG POSTS WITH 3/8" X 6 1/2" CARRIAGE BOLTS AND TORQUE WASHERS AND A 3/8" WASHER WITH 3/8" LOCKNUT ON THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS.






## STEP 26: CL-CORNER POST

1. PLACE THE 4 X 4 X 131" CL-CORNER POSTS FLUSH WITH THE OUTSIDE END OF THE CL-DECK SUPPORT, LINING UP THE HOLES. FASTEN FROM THE OUTSIDE WITH 3/8" X 6 1/2" CARRIAGE BOLTS AND TORQUE WASHERS AND A 3/8" WASHER WITH A 3/8" LOCKNUT ON THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS.




## STEP 27: BLOCK SUPPORTS

1. PLACE A 4 X 4 X 70" BLOCK SUPPORTS WITH FIVE HOLES (THE SIDE WITH 2 COUNTERSUNK HOLES FACES DOWN AND THE SIDE WITH 3 COUNTERSUNK HOLES FACES IN) FLUSH AGAINST THE CL-CORNER LAG POST AND CL-CENTER POST AND FLUSH WITH THE BOTTOM OF THE CL-DECK SUPPORTS. FASTEN WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHER.
2. PLACE A 4 X 4 X 70" BLOCK SUPPORTS WITH FIVE HOLES (THE SIDE WITH 2 COUNTERSUNK HOLES FACES DOWN AND THE SIDE WITH 3 COUNTERSUNK HOLES FACES IN) FLUSH AGAINST THE CL-CORNER POST AND FLUSH WITH THE BOTTOM OF THE CL-DECK SUPPORTS. FASTEN WITH 3/8" X 5" LAG SCREWS AND 3/8" WASHERS IN ALL ALL COUNTERSUNK HOLES EXCEPT THE CENTER ONE AT THIS TIME.



## STEP 28: BACK STARTER BOARDS


1. PLACE A 2 X 6 X 70" BACK STARTER BOARD (HOLES OFFSET UP) FLUSH WITH THE FRONT AND BOTTOM OF THE CL-CORNER POSTS. THEN PLACE ANOTHER 2 X 6 X 70" BACK STARTER BOARD (HOLES OFFSET DOWN) FLUSH WITH THE INSIDE AND BOTTOM OF THE CL-CORNER POSTS. FASTEN WITH 3/8" X 3 1/2" LAG SCREWS AND 3/8" WASHERS AT THE POST, CENTER HOLE USED IN THE FOLLOWING STEP.






## STEP 29: CL-BOTTOM SPACER & CL-CENTER POST

1. PLACE THE 4 X 6 X 63" CL-BOTTOM SPACER BETWEEN THE TWO 2 X 6 X 70" BOTTOM SPACER BOARDS, AS SHOWN BELOW. FASTEN THE TWO BOTTOM SPACER BOARDS TO THE CL-BOTTOM SPACER WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.
2. PLACE THE 4 X 4 X 43" CL-CENTER POST FLUSH WITH THE CL-BLOCK SUPPORT LINING UP THE HOLE OF THE CL-CENTER POST WITH THE CENTER HOLE OF THE BLOCK SUPPORT. FASTEN THE CL-CENTER POST FROM THE OUTSIDE WITH 3/8" X 6 1/2" CARRIAGE BOLTS AND TORQUE WASHERS THEN 3/8" WASHERS AND 3/8" LOCKNUTS FROM THE INSIDE. USE BOLT CAPS TO COVER ALL EXPOSED THREADS.



## STEP 30: CL-CENTER DECK SUPPORTS


1. PLACE A 2 X 4 X 30 3/4" CL-CENTER DECK SUPPORT ON EITHER SIDE OF THE CL-CENTER POSTS AND ON TOP OF THE BLOCK SUPPORTS (HOLES OFFSET DOWN ON ONE SIDE AND UP ON THE OTHER), AS SHOWN BELOW. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.





## STEP 31: BLOCKS

1. PLACE THE 4 X 4 X 25" BLOCKS (COUNTERSUNK HOLES OFFSET UP) ON TOP OF THE BLOCK SUPPORTS, BETWEEN THE CL-CENTER DECK SUPPORTS AND CL-DECK SUPPORTS. FASTEN THE BLOCKS TO THE BLOCK SUPPORTS WITH 3/8" x 5" LAG SCREWS AND 3/8" WASHERS.




## STEP 32: ASSEMBLY OF UPPER DECK

1. PLACE THE PRE-ASSEMBLED 4- CL-DECK BOARD SECTION ON TOP OF DECK SUPPORTS, AS SHOWN BELOW. BE SURE THE DECK IS EVENLY SPACED AND CENTERED BETWEEN ALL POST. SECURE WITH TWO 2" WOOD SCREWS TO EACH DECK SUPPORT ON EACH DECK BOARD.




## STEP 33: DECK SPACER BOARDS

1. PLACE TWO  $5/4 \times 3 \frac{1}{2} \times 29 \frac{3}{4}$ " DECK SPACER BOARDS ACROSS THE TOP OF THE CL-DECK SUPPORTS AND CL-CENTER DECK SUPPORTS BETWEEN THE CL-CORNER LAG POST AND CL-CENTER LAG POST.
2. PLACE TWO  $5/4 \times 3 \frac{1}{2} \times 29 \frac{3}{4}$ " DECK SPACER BOARDS ACROSS THE TOP OF THE CL-DECK SUPPORTS AND CL-CENTER DECK SUPPORTS BETWEEN THE CL-CORNER POST AND CL-CENTER POST.
3. SECURE DECK SPACER BOARDS WITH FOUR  $2 \frac{1}{2}$ " WOOD SCREWS TO DECK SUPPORTS.




## STEP 34: POST PANEL

1. PLACE THE PRE-ASSEMBLED POST PANEL FLUSH AGAINST THE CL-CORNER POSTS, ALLOWING THE PANEL SLATS TO REST ON TOP OF THE DECK. FASTEN THE POST PANEL TO THE BACK CL-CORNER POST AND CL-CENTER POSTS WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 35: PICNIC TABLE SUPPORTS


1. PLACE TWO 2 X 4 X 34" PICNIC TABLE SUPPORTS, PER SIDE, FLUSH WITH THE CORNER POSTS AND CL-CORNER POST AT THE HEIGHT SHOWN. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.






## STEP 36: PICNIC TABLE & SEATS

1. PLACE THE 2 X 6 X 62 3/4" PICNIC TABLE SEATS ON THE LOWER PICNIC TABLE SUPPORTS AND FLUSH WITH THE END OF THE PICNIC TABLE SUPPORTS, AS SHOWN BELOW. SECURE WITH TWO 2 1/2" WOOD SCREWS TO PICNIC TABLE SUPPORTS PER SIDE ON EACH PICNIC TABLE SEAT.
2. PLACE THE 3-BOARD PICNIC TABLE ON THE UPPER PICNIC TABLE SUPPORTS AND CENTER BETWEEN ALL POST, AS SHOWN BELOW. SECURE WITH TWO 2" WOOD SCREWS TO PICNIC TABLE SUPPORTS PER SIDE ON EACH PICNIC TABLE BOARD.




## STEP 37: CL-ROOF PANELS

1. PLACE THE PRE-ASSEMBLED CL-ROOF PANEL WITH HOLE AT 4 1/2" FLUSH WITH THE FORT ROOF SUPPORT AND THE 45° END FACING TOWARD THE OUTSIDE, AS SHOWN BELOW. FASTEN THE ROOF SUPPORT TO THE CL-CORNER LAG POST FROM THE OUTSIDE WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS. DO NOT TIGHTEN BOLTS COMPLETELY AT THIS TIME.
2. PLACE THE PRE-ASSEMBLED CL-ROOF PANEL WITH HOLE AT 5 3/4" WITH THE 45° END FACING TOWARD THE INSIDE. FLUSH THE TWO 45° ENDS TOGETHER OF THE ROOF PANELS TO MAKE A PEAK. FASTEN THE ROOF SUPPORT TO THE CL-CORNER POST FROM THE OUTSIDE WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS. TIGHTEN ALL BOLTS COMPLETELY AT THIS TIME.




## STEP 38: COMPLETION OF ROOF

1. AFTER BOTH ROOF PANELS ARE FASTENED, NAIL THE TWO ROOF SUPPORTS TOGETHER WITH 2 1/2" WOOD SCREWS, PERPENDICULAR AT THE MITER JOINTS, AS SHOWN BELOW.
2. PLACE ROOF PEAK ON TOP OF ROOF, FLUSH WITH ROOF PANELS AND ROOF SUPPORTS. FASTEN RIDGE CAP TO ROOF WITH 1 1/4" WOOD SCREWS, FOUR ON EACH SIDE, CENTERED AND EVENLY SPACED AS SHOWN BELOW.



## STEP 39: ROPE LADDER

1. SET THE 4 X 6 X 112" ROPE LADDER SUPPORT ON TOP OF TOP PANEL BOARD AND FLUSH WITH BOTH PORCH POSTS AND CENTER POST. COUNTERSUNK HOLES FACE OUTWARD AND ARE CENTERED ON ALL THREE POST. FASTEN ROPE LADDER SUPPORT TO ALL THREE POST WITH 3/8 X 5" LAG SCREWS AND 3/8" WASHERS, AS SHOWN BELOW.
2. FLUSH THE BOTTOM OF 4 X 4 X 75" ROPE LADDER RUNNER WITH THE BOTTOM OF LADDER. COUNTERSUNK HOLES FACE INWARD AND ARE CENTERED ON LADDER LEGS. FASTEN ROPE LADDER RUNNER TO EACH LADDER LEG WITH 3/8 X 5" LAG SCREWS AND 3/8" WASHERS.
3. THREAD THE ROPE THROUGH THE HOLES IN THE ROPE LADDER SUPPORT FROM THE BOTTOM TO THE TOP. THEN FORM A SECURE KNOT AT THE TOP OF THE ROPE LADDER SUPPORT. THEN THREAD THE ROPE THROUGH THE FRONT SIDE OF THE ROPE LADDER RUNNER TO THE BACK SIDE. THEN FORM A SECURE KNOT AT THE BACK OF THE ROPE LADDER RUNNER.
4. TEST EACH ROPE BY WRAPPING IT AROUND YOUR HAND. IF THE ROPE WRAPS AROUND YOUR HAND IT IS TOO LOOSE. RE-TIE THE ROPE UNTIL IT NO LONGER WRAPS AROUND YOUR HAND.





## STEP 40: FLOWER BOX

1. PLACE FLOWER BOX FLUSH AGAINST SIDE WALL PANEL JUST UNDER THE WINDOW. FASTEN WITH FOUR 1 1/2" WOOD SCREWS EVENLY SPACED AND CENTERED FROM INSIDE FLOWER BOX AND INTO SIDE WALL PANEL. THIS MAY BE DONE FROM INSIDE FORT THROUGH THE WINDOW OR FROM OUTSIDE USING A LADDER.

1 1/2" WOOD SCREW

FLOWER BOX




FLOWER BOX




## STEP 41: 14' SCOOP SLIDE

1. PLACE THE 14' SCOOP SLIDE FLUSH ON TOP OF THE CL-DECK BOARDS THEN CENTER BETWEEN THE CL-CORNER LAG POST AND THE CL-CORNER POST. ATTACH SLIDE TO CL-DECK BOARDS WITH THREE 1 1/4" PAN HEAD SCREWS.
2. PLACE THE 2 X 4 X 30 3/4" CL-TOP PANEL BOARD (HOLES OFFSET UP) FLUSH WITH THE CL-CORNER POST AND CORNER LAG POST. FLUSH THE TOP OF THE CL-TOP PANEL BOARD WITH THE TOP OF THE POST PANEL AS SHOWN BELOW. FASTEN WITH 3/8 X 3 1/2" LAG SCREWS AND 3/8" WASHERS.




## STEP 42: DINNER BELL

1. CENTER THE BASE OF THE DINNER BELL ON THE ROPE LADDER SUPPORT AND ATTACH WITH PROVIDED SCREWS.
2. ASSEMBLE THE BELL AND TIGHTEN TO THE BASE WITH THE PROVIDED NUT.




## STEP 43: TELESCOPE

1. WITH THE 1-1/4" WOOD SCREWS PROVIDED IN THE TELESCOPE BAG, FASTEN ONE OF THE CIRCLE TELESCOPE BRACKETS ONTO THE ROPE LADDER SUPPORT.
2. PLACE THE TELESCOPE STAND AND TELESCOPE INTO THE SLOT OF THE TELESCOPE BRACKET.
3. FASTEN THE REMAINING TELESCOPE BRACKET TO THE OPPOSITE SIDE THAT THE FIRST TELESCOPE BRACKET WAS INSTALLED ON WITH 1-1/4" WOOD SCREWS.



TELESCOPE  
HARDWARE





TELESCOPE

PLACEMENT VIEW



## STEP 44: FLAGS & NAMEPLATE

1. ATTACH THE PLAYNATION NAMEPLATE CENTERED ON THE FRONT OF THE ROPE LADDER SUPPORT BEAM WITH TWO 2 1/2" WOOD SCREWS.
2. THE PLASTIC FLAG KITS CONSIST OF ONE FLAG, ONE FLAG BASE AND HARDWARE. THE FLAGS WILL BE INSTALLED ON THE FRONT SIDE OF THE ROPE LADDER SUPPORT BEAM, ONE AT EACH END.
3. NO SPECIFIC MEASUREMENT ARE NEEDED, BUT THE FLAGS BASE MAY BE PLACED 1" FROM THE TOP OF THE BEAM AND 3" FROM THE END. PLACE THE FLAG BASE AGAINST THE BEAM AND SECURE WITH THE 1/2" PHILLIPS HEAD SCREWS PROVIDED. PLACE THE FLAG INTO THE FLAG BASE.



# STEP 45: STEERING WHEEL

1. PLACE THE STEERING WHEEL INSERT INSIDE THE STEERING WHEEL.
2. USE THE HARDWARE INCLUDED WITH THE STEERING WHEEL TO MOUNT THE STEERING WHEEL TO THE 4 X 4 CENTER POST AT THE FRONT OF THE PLAYSET. DO NOT OVER-TIGHTEN THE LAG SCREW INTO THE STEERING WHEEL, OR IT WILL NOT TURN.
3. PLACE THE STEERING WHEEL CAP OVER THE CENTER OF THE STEERING WHEEL.





## STEP 46: 5' SUPER SCOOP WAVE SLIDE


1. PLACE THE 5' SUPER SCOOP WAVE SLIDE ON TOP OF THE DECK OVERLAPPING THE DECK BOARD. CENTER THE SLIDE BETWEEN THE PORCH POST AND THE CENTER POST. ATTACH SLIDE TO THE UPPER DECK BOARDS WITH THREE 1 ¼" PAN HEAD SCREWS.



5' SUPER SCOOP WAVE SLIDE


## STEP 47: PLASTIC SAFETY HANDLES

1. PLACE EACH PLASTIC SAFETY HANDLE CENTERED ON THE INSIDE FACE OF THE POSTS SHOWN BELOW. ADJUST EACH HANDLE UP OR DOWN TO SUIT THE NEEDS OF YOUR CHILD. ATTACH EACH SAFETY HANDLE TO THE POST WITH TWO PAN HEAD SCREWS AND TWO WASHERS PROVIDED WITH THE SAFETY HANDLES.




## STEP 48: TOP PANEL BOARD

1. PLACE THE TOP OF THE 2 X 4 X 70" TOP PANEL BOARD FLUSH TO THE TOP OF THE 4 X 4 X 53" CL-CENTER LAG POST.
2. ATTACH THE TOP PANEL BOARD TO THE CORNER LAG POSTS AND CENTER LAG POST WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS.



## STEP 49: ROOF END CAPS

1. ATTACH A 5/4 X 3-1/2" X 73" ROOF END CAP TO THE END OF THE ROOF SUPPORTS ON THE FRONT PORCH PANEL WITH FOUR 2" WOOD SCREWS; TWO SCREWS PER SIDE.
2. ATTACH ANOTHER 5/4 X 3-1/2" X 73" ROOF END CAP TO THE END OF THE ROOF SUPPORTS ON THE CL ROOF PANEL AT THE REAR OF THE PLAY SET WITH FOUR 2" WOOD SCREWS; TWO PER SIDE.




# **UNIT B**


**(Connector Bridge that spans between UNIT A and UNIT C.)**




3/8" x 5"  
LAG SCREW  
QTY: 8




3/8" x 3-1/2"  
LAG SCREW  
QTY: 16




TORQUE  
WASHER  
QTY: 12



3/8" WASHER  
QTY: 36



3/8" X 6-1/2"  
CARRIAGE BOLT  
QTY: 12



#8 X 1-1/4"  
WOOD SCREW  
QTY: 8



#8 X 1-1/2"  
WOOD SCREW  
QTY: 20



#8 X 2"  
WOOD SCREW  
QTY: 80




#8 X 2-1/2"  
WOOD SCREW  
QTY: 88



#8 X 3"  
WOOD SCREW  
QTY: 2










3/8" LOCK NUT  
QTY: 12















3/8" BOLT CAP  
QTY: 12



USE THE RULER TO THE RIGHT TO MEASURE YOUR BOLTS AND SCREWS. PICTURE VIEWS SHOWN ABOVE ARE 1:1 SCALE AND CAN BE USED TO MATCH BOLT AND SCREW SIZES.

PICTURE	DESCRIPTION	QTY.
	2 X 4 X 24" BRIDGE DECK BOARD	<b>1</b>
	2 X 4 X 103" BRIDGE RAIL	<b>2</b>
 <p data-bbox="532 709 1062 808">NOTE FOR 2011 MODEL THERE ARE TWO COUNTERSUNK HOLES IN THIS BOARD.</p> <p data-bbox="630 835 1078 940">USE 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS TO ATTACH IF COUNTERSUNK HOLES EXIST IN BOARD.</p>	2 X 6 X 24" END CAP	<b>2</b>
	2 X 6 X 24" BRIDGE DECK BOARD	<b>19</b>
	4 X 4 X 57" BRIDGE CORNER POST	<b>4</b>
	4 X 6 X 103" BRIDGE SWING BEAM	<b>1</b>
	4 X 6 X 103" BRIDGE BEAM	<b>1</b>

PICTURE	DESCRIPTION	QTY.
	5/4 X 2 X 14" SMALL RAY	<b>4</b>
	5/4 X 2 X 16" MEDIUM RAY	<b>4</b>
	5/4 X 2 X 17" LARGE RAY	<b>2</b>
	5/4 X 6 X 32" PANEL SLAT	<b>18</b>
	34"W X 45"L ROOF SECTION	<b>2</b>
	34" W ROOF PEAK	<b>1</b>
	72"W SUN/SUN SUPPORT ASSEMBLY	<b>2</b>


PICTURE	DESCRIPTION	QTY.
	<p>CHIMNEY (UNASSEMBLED)</p>	<p><b>1</b></p>
	<p>IRON DUCTILE SWING HANGER</p>	<p><b>4</b></p>
	<p>PERISCOPE</p>	<p><b>1</b></p>
	<p>SNAP HOOK</p>	<p><b>4</b></p>
	<p>SWING BELT WITH CHAINS</p>	<p><b>2</b></p>
		<p>160</p>

# STEP 1: ATTACHING IRON DUCTILE SWING HANGERS

1: LOCATE FOUR IRON DUCTILE SWING HANGERS AND ONE 4 X 6 X 103" BRIDGE SWING BEAM.

2: PLACE A TORQUE WASHER OVER THE END OF A 3/8" X 6-1/2" CARRIAGE BOLT. PLACE THE CARRIAGE BOLT INTO THE COUNTERBORED HOLE IN THE TOP OF THE BRIDGE SWING BEAM. LINE UP THE SQUARE SHANK UNDER THE HEAD OF THE BOLT WITH THE SQUARE CUTOUT IN THE TORQUE WASHER. HAMMER THE HEAD OF THE CARRIAGE BOLT TO SEAT THE TORQUE WASHER TEETH INTO THE BOTTOM OF THE COUNTERBORED HOLE. REPEAT THIS PROCESS FOR THE REMAINING SEVEN COUNTERBORED HOLES IN THE TOP OF THE BRIDGE SWING BEAM.

3: PLACE AN IRON DUCTILE SWING HANGER OVER THE ENDS OF THE CARRIAGE BOLTS. FASTEN EACH IRON DUCTILE SWING HANGER TO THE BRIDGE SWING BEAM WITH 3/8" WASHERS AND 3/8" LOCK NUTS. PLACE BOLT CAPS OVER ANY EXPOSED THREADS. REPEAT THIS PROCESS THREE MORE TIMES WITH THE IRON DUCTILE SWING HANGERS AND HARDWARE.






## STEP 2: ATTACH 4 X 6 BEAMS TO PLAY SETS

1: PLACE THE 4 X 6 X 103" BRIDGE SWING BEAM ON TOP OF THE UPPER LEVEL DECK OF BOTH PLAY SETS. THIS BEAM WILL BE ON THE FRONT SIDE OF THE PLAY SETS.

2: PLACE THE 4 X 6 X 103" BRIDGE BEAM ON THE TOP OF THE UPPER LEVEL DECK OF BOTH PLAY SETS. THIS BEAM WILL BE ON THE REAR SIDE OF THE PLAY SETS.

3: ALIGN THE ENDS OF THE BEAMS WITH THE INSIDE OF THE CORNER POSTS ON ONE PLAY SET. GOT TO THE DECK OF THE OTHER PLAY SET AND CHECK TO MAKE SURE THE OTHER ENDS OF THE BEAMS ARE FLUSH TO THE INSIDE OF THE CORNER POSTS OR ALMOST FLUSH.


4: ATTACH THE BEAMS ON EACH END WITH TWO 3/8" X 5" LAG SCREWS AND TWO 3/8" WASHERS.



## STEP 3: END CAPS

1: LOCATE TWO 2 X 6 X 24" END CAPS.

2: ATTACH EACH END CAP TO THE ENDS OF THE 4 X 6 X 103" MAIN BEAMS WITH FOUR #8 X 2-1/2" WOOD SCREWS.




## STEP 4: BRIDGE DECK BOARDS

1: LOCATE NINETEEN 2 X 6 X 24" BRIDGE DECK BOARDS AND ONE 2 X 4 X 24" BRIDGE DECK BOARD.



2: ARRANGE THE DECK BOARDS AS SHOWN BELOW BUTTING THEM UP NEXT TO ONE ANOTHER. EACH END OF THE DECK BOARDS SHOULD BE FLUSH WITH THE SIDES OF THE MAIN BEAMS; OR THE ENDS CAN BE SLIGHTLY TOWARD THE INSIDE OF THE SIDES OF THE MAIN BEAMS. AFTER THE BOARDS ARE ARRANGED AS SHOWN THEY MAY OVERHANG ON EACH END. ADJUST THE DECK BOARDS SO THE OVERHANG ON EACH END IS EQUAL.

3: SECURE EACH DECK BOARD TO THE BRIDGE MAIN BEAMS WITH FOUR #8 X 2-1/2" WOOD SCREWS.



# STEP 5: DRILL CORNER POST HOLES

- 1: LOCATE FOUR 4 X 4 X 57" BRIDGE CORNER POSTS.
- 2: MEASURE AS SHOWN BELOW AND MAKE MARKS.
- 3: DRILL A 1/4" HOLE X 2-1/2" DEEP IN EACH POST.
- 4: DRILL TWO LEFT AND TWO RIGHT POSTS. USE A PENCIL TO WRITE AN "L" ON TOP OF THE LEFT POSTS AND AN "R" ON TOP OF THE RIGHT POSTS.






## STEP 6: INSTALL CORNER POSTS

1: PLACE THE CORNER POSTS IN THE POSITIONS SHOWN BELOW.

2: ATTACH THE TOP HOLE IN EACH CORNER POST TO THE MAIN BEAMS WITH A 3/8" X 6-1/2" CARRIAGE BOLT AND A 3/8" WASHER ON THE INSIDE. ON THE OUTSIDE USE A 3/8" WASHER AND A 3/8" LOCK NUT IN THE COUNTERBORED TOP HOLE IN THE CORNER POST. USE A BOLT CAP TO COVER ANY EXPOSED THREADS.

3: SQUARE EACH CORNER POST TO THE MAIN BEAM IT IS FASTENED ONTO. WITH THE CORNER POST SQUARE PLACE A 3/8" X 5" LAG SCREW WITH 3/8" WASHER IN THE BOTTOM HOLE IN THE CORNER POST AND DRIVE IT IN.






## STEP 7: INSTALL BRIDGE RAILINGS

**TIP:** BEFORE DOING THIS STEP LOCATE THE BRIDGE ROOF SECTIONS WHICH ARE PREASSEMBLED. STOW THE ROOF SECTIONS ON THE REAR DECK OF UNIT C.

1: LOCATE TWO 2 X 4 X 103" BRIDGE RAILS.

2: PLACE THE TOP SURFACE OF EACH BRIDGE RAIL 29" OFF THE TOP OF THE DECK BOARDS. EACH END OF THE BRIDGE RAIL SHOULD BE FLUSH OR ALMOST FLUSH TO THE PLAY SET CORNER POST INSIDE SURFACE.

3: ATTACH EACH BRIDGE RAIL TO THE 4 X 4 X 57" CORNER POSTS AND THE PLAY SET CORNER POSTS WITH FOUR 3/8" X 3-1/2" LAG SCREWS AND FOUR 3/8" WASHERS.



## STEP 8: ROOF SECTIONS


1: LOCATE TWO BRIDGE ROOF SECTIONS. (IF YOU FOLLOWED THE TIP IN STEP 7 THEN THEY SHOULD BE ON THE REAR DECK OF UNIT C.)

2: PLACE THE ROOF SECTION ON THE LEFT OVER THE CORNER POSTS AND LINE UP THE HOLES. ATTACH THE ROOF SECTION TO THE CORNER POSTS WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS. LEAVE THE LAG SCREWS SLIGHTLY LOOSE.

3: PLACE THE ROOF SECTION ON THE RIGHT OVER THE CORNER POSTS AND LINE UP THE HOLES. ATTACH THE ROOF SECTION TO THE CORNER POSTS WITH 3/8" X 3-1/2" LAG SCREWS AND 3/8" WASHERS. LEAVE THE LAG SCREWS SLIGHTLY LOOSE.

4: ALIGN THE ROOF SECTIONS AT THE PEAK AND TIGHTEN THE LAG SCREWS.

5: SECURE THE ROOF SECTIONS TOGETHER WITH TWO 3" WOOD SCREWS GOING THROUGH THE ROOF STARTER THEN THROUGH THE ROOF SUPPORT THEN INTO THE OPPOSING ROOF SUPPORT.




## STEP 9: BRIDGE ROOF PEAK

1: LOCATE THE 34" L BRIDGE ROOF PEAK.

2: PLACE THE ROOF PEAK AS SHOWN BELOW FLUSH WITH THE ENDS OF THE ROOF BOARDS.


3: ATTACH THE ROOF PEAK TO THE ROOF BOARDS WITH #8" X 1-1/4" WOOD SCREWS.






## STEP 10: CHIMNEY

- 1: LOCATE THE CHIMNEY FOR THE BRIDGE.
- 2: ASSEMBLE THE CHIMNEY AS DESCRIBED IN THE INSTRUCTIONS THAT ARE INCLUDED.
- 3: POSITION THE CHIMNEY AS SHOWN BELOW AND ATTACH THE CHIMNEY BLOCK AS DESCRIBED IN THE INSTRUCTIONS.
- 4: ATTACH THE CHIMNEY TO THE CHIMNEY BLOCK AS DESCRIBED IN THE INSTRUCTIONS.



# STEP 11: SUN/SUN SUPPORT ASSEMBLIES

- 1: LOCATE TWO SUN/SUN SUPPORT ASSEMBLIES.
- 2: THE "FLUSH" SIDE OF THE ASSEMBLY SHOULD FACE THE INSIDE OF THE BRIDGE. THE FLUSH SIDE OF THE SUN SUPPORT CONTACTS THE CORNER POSTS.
- 3: POSITION THE ANGLED ENDS OF THE SUN SUPPORT UNDER THE ROOF SUPPORTS AND FLUSH TO THE OUTSIDE OF THE CORNER POSTS.
- 4: FASTEN EACH SUN/SUN SUPPORT TO THE CORNER POSTS WITH #8 X 2" WOOD SCREWS.








## STEP 12: PREDRILL RAYS




1: LOCATE FOUR 5/4 X 2 X 14" SMALL RAYS, FOUR 5/4 X 2 X 16" MEDIUM RAYS AND TWO 5/4 X 2 X 17" LARGE RAYS.

2: USE A 1/8" DRILL BIT TO DRILL TWO HOLES IN EACH RAY AS SHOWN BELOW.




# STEP 13: INSTALL SUN RAYS

- 1: PLACE THE SUN RAYS ARRANGED AS SHOWN BELOW.
- 2: ATTACH EACH SUN RAY TO THE SUN AND THE ROOF SUPPORT WITH TWO #8 X 1-1/2" WOOD SCREWS.
- 3: ATTACH THE REMAINING SUN RAYS ON THE OTHER SIDE OF THE BRIDGE.




## STEP 14: PANEL SLATS

- 1: LOCATE EIGHTEEN 5/4 X 6 X 32" PANEL SLATS.
- 2: DRILL 1/8" DIAMETER HOLES IN EACH PANEL SLAT AS SHOWN BELOW.
- 3: USE THE DIMENSIONS SHOWN BELOW TO ATTACH EACH PANEL SLAT WITH #8 X 2" WOOD SCREWS.
- 4: ATTACH NINE PANEL SLATS ON EACH SIDE.



## STEP 15: PERISCOPE

- 1: LOCATE THE BAGGED PERISCOPE.
- 2: PLACE THE PERISCOPE MOUNTING BRACKET AGAINST THE FRONT 2 X 4 X 103" RAILING ON THE INSIDE.
- 3: USE THE INCLUDED PHILLIPS PAN HEAD SCREWS TO ATTACH THE MOUNTING BRACKET TO THE RAILING.
- 4: SNAP THE PERISCOPE INTO THE MOUNTING BRACKET.




## STEP 16: SWING BELTS

1: SNAP A SNAP HOOK OVER THE EYELET IN EACH IRON DUCTILE SWING HANGER.

2: SNAP ONE CHAIN ON EACH SNAP HOOK. ADJUST CHAINS UP OR DOWN TO SUIT THE NEEDS OF YOUR CHILD. EXCESS CHAIN MAY BE LOOPED AND SNAPPED INSIDE THE SNAP HOOK.


DETAIL A  
SCALE 1 : 4



EYELET IN SWING HANGER

SNAP HOOK

CHAIN




SWING BELT  
WITH CHAINS



# WARRANTY REGISTRATION

- ABBY'S PALACE -

PlayNation manufactures the finest quality products that are designed for outstanding strength and durability. We back our products with an unparalleled warranty. In the unlikely event that you will need to contact us about covered repairs, we must have a valid Warranty Registration on file.

3 EASY WAYS TO REGISTER	
OPTION 1	Fax this completed form to: <b>(800) 880-3300</b> <b>OR</b> Mail this completed form to: <b>PlayNation Playsets</b> 190 Etowah Industrial Court Canton, GA 30114
OPTION 2	Complete the online registration form at: <a href="http://www.playnation.com/register">http://www.playnation.com/register</a>
OPTION 3	Scan this QR Code with your smart phone to complete the form using your phone 

## Where did you buy this product?:

Date of Purchase \_\_\_\_\_ Store \_\_\_\_\_ Store City \_\_\_\_\_ Store State \_\_\_\_\_

## Your registration information:

Name: \_\_\_\_\_ Email: \_\_\_\_\_

Address: \_\_\_\_\_  
Street City State Zip

Please select your age?  18-30  31-40  41-50  51+

How old are your children?  2-3  4-5  6-7  8+

How would you rate the quality of this product?  
 ★★★★★ Excellent  
 ★★★★ Above Average  
 ★★★ Average  
 ★★ Below Average  
 ★ Poor

Would you recommend this product to friends & family?  Yes  No

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_